



QEPParts.com
888-634-4289
An iBuy Stores Company

REF.	PART	
<u>NO.</u>	<u>NO.</u>	<u>DESCRIPTION</u>
1.	1575	Screw–Handle/Valve Housing/ Body (4 ea.) (Socket Cap 1/4-20 x 1/2")
2.	50454	Screws – Magazine / Standoff (2 ea.) (Socket Cap 8-32 x 1-1/5")
3.	50280	Washer – Return Spring (2 ea.)
4.	50010	Screw – Shoe / Body (2 ea.) (Socket Set 5/16-18 x 2-1/4")
5.	50294	Cylinder Cushion Ring
6.	50012	Head Gasket
7.	50013	Cylinder Exhaust Valve
8.	50018	Spring - Return
9.	50019	Spring - Discharge (3 ea.)
10.	50020	Piston Cushion
11.	50023	Discharge Valve & O-Rings
12.	50025	Cylinder & O-Rings
13.	50015	Valve Body & O-Ring
14.	50431	Gate Clip & Pin
15.	50160	Extension Handle Assembly W/Safety (Includes 39,40,45)
16.	50455	Nut – Magazine / Standoff Screws (2 ea.) (Nyloc 8-32)
17.	50450	Spring - Constant Force & Screw (Ref. 18)
18.	50308	Screw – Constant Force Spring (Socket Cap 8-32 x 3/16")
19.	50452	Magazine Standoff
20.	50448	Spindle Cap

21. 50187 Guide Assembly (Includes 14,22)
22. 50188 Gate
23. 50189 Restrictor Plate
24. 50447 Spindle – Constant Force Spring
25. 50453 Spring – Compression – Pusher Finger /
Pusher Bracket
26. 50158 Rail
27. 50186 Magazine Retainer Bracket
28. 50457 Magazine
29. 50164 Screws – Guide / Magazine / Bracket (4 ea.)
(Socket Flat Head 10-32 x 5/16”)
30. 50103 Ram Washer
31. 50180 Shoe Base Pad – 3/4” Flooring
32. 50183 Shoe Base – 3/4” Flooring
33. 50320 Flange Nut – Shoe / Body (2 ea.) (Serrated
Flange Nut 5/16-18)
34. 50125 Shoe - Angled
35. 50126 Screws – Valve Housing / Body (4)
(Socket Cap 10-24 x 1-1/2”)W/4 Washers
(Ref. 44)
36. 50198 Piston / Driver Blade & O-Ring Assembly
(Includes 55,56,57,58, & O-Ring)
37. 50445 Pusher Pivot Pin (Includes 38)
38. 50449 Lock Ring – Pusher Pivot Pin
39. 50140 Safety Stem
40. 50142 Cover – Safety
41. 50152 Main Valve Assembly & O-Rings
42. 50177 Screw – Face Shoe

- (Machine Flat Head Phillips 1/4-20 x 3/8")
43. 50154 Screws – Magazine/Retainer Bracket (2 ea.)
(Socket Button Head 10-32 x 5/16")
44. 50155 Washers – Valve Housing Screws (4 ea.)
45. 50161 Spring – Safety
46. 50162 Valve Housing Assembly
47. 50163 Ram Head Assembly W/Cap & Screw
(Ref. 52 & 54)
48. 50477 Face Shoe
49. 50444 Pusher Finger
50. 2503 Screws – Shoe / Pad / Magazine / Cylinder
Exhaust Valve (4 ea.)
(Machine Flat Head Phillips 1/4-20 x 3/4")
51. 2600 Screws – Shoe Base (4 ea.)
(Machine Flat Head 1/4-20 x 1")
52. 9009 Screw – Ram Head / Main Valve
(Socket Set Screw 1/4 -28 x 1/2" w/Patch)
53. 50281 Hex Adapter –3/8 NPT (Female) x
3/8 NPT (Male)
54. 40030 Ram Cap – Rubber
55. 50419 Piston Insert
56. 50420 Piston
57. 50329 Washer – Driver Blade / Piston
58. 50197 Driver Blade
59. 50443 Pusher Bracket

888-634-4289

An iBuy Stores Company

ACCESSORIES

The testing of this tool has been accomplished with the following accessories. For safest operation, it is recommended that only these accessories be used with this product.

WARNING- Since accessories other than those listed have not been tested with this product; use of such accessories could be hazardous.

<u>REF.</u> <u>NO.</u>	<u>PART</u> <u>NO.</u>	<u>DESCRIPTION</u>
Not Shown	50104	O-Ring Repair Kit
Not Shown	50172	Grease
Not Shown	50200	Shoe Base & Pads for 9/16" Flooring (Black)
Not Shown	50201	Shoe Base & Pads for 3/4" Flooring (Natural)
Not Shown	50202	Shoe Base & Pads for 33/32" Flooring (Green)
Not Shown	50139	Hex Wrenches
Not Shown	50318	Wrench – Shoe / Body Flange Nuts
Not Shown	50458	Hammer "V" Head
Not Shown	50170	Safety Glasses
Not Shown	50210	Case - PORTAMATIC®
Not Shown	42623	2" Porta-Nails 10 packages of 1000 Nails
Not Shown	42640	1-1/2" Porta-Nails - Box of 1000 Nails
Not Shown	42646	1-3/16" Porta-Nails - Box of 1000 Nails
Not Shown	42620	Porta-Nail Set Tool