


# Comfort Glow®

## UNVENTED (VENT-FREE) GAS STOVE HEATER OWNER'S OPERATION AND INSTALLATION MANUAL



### MODELS CSBNT AND CSBPT

Propane/LP and Natural Gas Thermostat Control Gas Log Heaters  
(Burner System For Cast Iron Stoves)


**⚠ WARNING:** If the information in this manual is not followed exactly, a fire or explosion may result causing property damage, personal injury or loss of life.

- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- **WHAT TO DO IF YOU SMELL GAS**
  - Do not try to light any appliance.
  - Do not touch any electrical switch; do not use any phone in your building.
  - Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
  - If you cannot reach your gas supplier, call the fire department.
- Installation and service must be performed by a qualified installer, service agency or the gas supplier.

**INSTALLER:** Leave this manual with the appliance.  
**CONSUMER:** Retain this manual for future reference.

# PARTS

MODELS 111485-01 AND 111485-02



## PARTS


This list contains replaceable parts used in your stove. For replacement parts see Replacement Parts on page 21 of this manual.

KEY NO.	PART NO.	DESCRIPTION			QTY
			111485-01	111485-02	
1	104026-01	Stove Log	•	•	1
2	098249-01	Nut, M5	•	•	2
3	**	Painted Base Assembly	•	•	1
4	104454-01	Bracket, Regulator	•	•	1
5	098867-10	Gas Regulator	•		1
	098867-14	Gas Regulator		•	1
6	104425-01	Inlet Tube	•	•	1
7	104424-03	Outlet Burner Tube	•	•	1
8	099056-19	Burner Orifice Injector	•		1
	099056-26	Burner Orifice Injector		•	1
9	111124-01	Burner Retainer Spring	•	•	1
10	102980-01	Burner	•	•	1
11	101329-22	Control Valve	•		1
	101329-21	Control Valve		•	1
12	104472-01	Bracket	•	•	1
13	099211-01	Screw	•	•	2
14	102445-01	Piezo Ignitor	•	•	1
15	099387-09	Pilot Tube	•	•	1
16	098271-10	Ignitor Cable	•	•	1
17	104286-01	ODS Pilot	•		1
	104285-01	ODS Pilot		•	1
18	M11084-38	Screw, Hex Head (#8-18 x 0.38)	•	•	7
<b>PARTS AVAILABLE — NOT SHOWN</b>					
	100563-01	Warning Plate	•	•	1
	101054-01	Lighting Instructions Plate	•	•	1
	100565-01	Warning Plate Fastener	•	•	1
	101137-04	Hardware Kit	•	•	1

\*\* Not a field replaceable part.

# PARTS

## STOVE BODY MODELS CSBNT AND CSBPT



## PARTS

### STOVE BODY MODELS CSBNT AND CSBPT

This list contains replaceable parts used in your stove. For replacement parts see Replacement Parts on page 21 of this manual.

KEY			
NO.	PART NO.	DESCRIPTION	QTY.
1	111698-07	Top Grate - Center	1
2	111698-11	Bottom Door	1
3	111531-01CK	Stove Dropped Pan (Black Only)	1
4	111698-14	Left Stove Door	1
5	111698-17	Right Stove Door	1
6	111698-20	Stove Leg	4
7	111764-01	Hardware Kit	1
8	111533-01	Screen Rod	1
9	111532-01CK	Stove Back Panel (Black Only)	1
10	111698-23	Door Knob	1
11	103297-04	Screen	1

**PARTS AVAILABLE — NOT SHOWN**

	104108-08	Touch-up Spray Paint 12 oz Can, Black	1
--	-----------	---------------------------------------	---

\* Included In Hardware Kit