




2315 / 303

Ref#	Part#	Description	Qty Reqd
1	10003645	LOG SET	1
2	10002175	FAN/ HEATER ASSEMBLY	1
3	10003587	FLAME GENERATOR MOTOR- 120V AC W/TERMINAL	1
4	10003095	CORD, POWER 16/3 HPN W/TERMINALS	1
5	10001393	ON/OFF SWITCH	1
6	10001971	HEATER CONTROL (THERMOSTAT)	1
7	10001639	HEATER CONTROL KNOB	1
8	0003442	DOOR GLASS W/GASKET	1
9	10003566	FLAME GENERATOR ASSEMBLY	1
10	10002159	EMBER BED (LIGHT FILTER)	1
11	10002150	LIGHT DIFFUSER (REAR SCREEN)	1
12	10002151	TINTED SCREEN	1
13	10003568	LIGHT BULB SOCKET W/WIRING ASSEMBLY	1
14	30000621	FRONT CLASSIC BLACK	1
14	30000787	FRONT MIDNIGHT BLACK	1
14	30000791	FRONT FOREST GREEN	1
15	30000622	END RIGHT/ LEFT CLASSIC BLACK	2
15	30000788	END RIGHT/ LEFT MIDNIGHT BLACK	2
15	30000792	END RIGHT/ LEFT FOREST GREEN	2
16	30000623	LEG CLASSIC BLACK	2
16	30000789	LEG MIDNIGHT BLACK	2
16	30000793	LEG FOREST GREEN	2
17	30000624	TOP CLASSIC BLACK	1

17	30000790	TOP MIDNIGHT BLACK	1
17	30000794	TOP FOREST GREEN	1
18	30000664	GLASS (NO GASKET)	1
19	30000776	GASKET, 3/4IN FLAT WINDOW - BLACK	1
20	10003524	MOUNTING BRACKET	1
32	10003093	BREAKER CIRCUIT MANUAL RESET	1
N/S	1601981	STUB, CONTROL DOOR (DOOR HANDLE STUB)	1
N/S	1600660	KNOB, THERM. HANDLE MAPLE (WOOD HANDLE)	1
N/S	1601396	GLASS CLIP	2