

Parts Catalogue



F80W

Wheeled paver

F80W S/N 4510075 - 4510124



***Your Partner
on the Road Ahead***

dynapac.com

General information

Use only authorized parts. Any damage or malfunction caused by the use of unauthorized parts is not covered by Warranty or Product Liability. Any unauthorized use or copying of the contents or any part thereof is prohibited. This applies in particular to trademarks, model denominations, part numbers, and drawings.

Instructions for use

This spare parts list contains no safety regulations and is merely intended to assist in the ordering of spare parts.

For information about operating, servicing, or repairing, the relevant Safety and operating instructions must be consulted at all costs.

Please observe the safety instructions listed in the relevant Safety and operating instructions!

Spare part catalogue F80W	1
001 - Engine	
Engine	2
001-010_Engine	
4812088145A Engine	3
001-010-001_Motor bracket	
4812088142 Motor bracket	5
001-010-002_Engine	
4812088144 Engine	6
001-010-003_Hydraulic pump	
4812088197 Hydraulic pump	8
001-010-031_Air distribution	
4812088358 Air distribution	9
002 - Drive	
Drive	10
002-010_Drive	
4812088137 Drive	11
002-020_Wheel assembly	
4812088122 Wheel assembly	13
003 - Mechanical	
Mechanical	15
003-010_Chassis	
4812088141 Chassis	16
003-010-004_Guide	
4812088124 Guide	18
003-010-005_Guide rod system	
4812088135 Guide rod system	20
003-010-007_Conveyor belt	
4812088131 Conveyor belt	21
003-010-007-005_Drive	
4812088130 Drive	23
4812088640 Drive	25
003-010-007-050 Fluid motor	
4812088200 Fluid motor	27
003-020_Hopper	
4812088136 Hopper	28
003-020-002_Left side cover	
4812088118 Left side cover	33
003-020-003_Right side cover	
4812088120 Right side cover	34


003-030_Cover hood	
4812088438 Cover hood	35
003-040_Running board	
4812088373 Running board	37
003-050_Reduction sheet	
4812088155 Reduction sheet	39
003 - Mechanical - S/N from 4510089 ff.	
Mechanical	40
003-010_Chassis	
4812088141 Chassis	See page 16
003-010-004_Guide	
4812088124 Guide	See page 18
003-010-005_Guide rod system	
4812088135 Guide rod system	See page 20
003-010-007_Conveyor belt	
4812088131 Conveyor belt	See page 21
003-010-007-005_Drive	
4812088130 Drive	See page 23
4812088640 Drive	See page 25
003-010-007-050 Fluid motor	
4812088200 Fluid motor	See page 27
003-020_Hopper	
4812088136A Hopper	46
003-021_Hopper weldment	
4812088644 Hopper weldment	51
003-022_Left side cover	
4812088645 Left side cover	52
003-023_Right side cover	
4812088646 Right side cover	53
003-030_Cover hood	
4812088438A Cover hood	54
003-031_Cover hood weldment	
4812088647 Cover hood weldment	56
003-040_Running board	
4812088373 Running board	See page 37
003-050_Reduction sheet	
4812088155 Reduction sheet	See page 39
004 - Screed	
Screed	59
004-010_Smoothing screed	

4812088371 Smoothing screed	60
004-020_Heating	
4812088367 Heating	64
004-020-001_Automatic ignition	
4812088162 Automatic ignition	66
004-020-002_Burner	
4812088164 Burner	67
004-020-100_Holder	
4812088426 Holder	69
004-020-110_Holder	
4812088660 Holder	70
004-030_Adaptor	
4812088087 Adaptor	71
004-040_Copying system	
4812088286 Copying system	72
004-040-010_Left carrier pulley	
4812088285 Left carrier pulley	73
004-040-020_Right carrier pulley	
4812088284 Right carrier pulley	75
004-050_Without vibration	
4812088270 Without vibration	77
005 - Hydraulic system	
Hydraulic system	78
005-010_Hydraulic oil tank	
4812088188 Hydraulic oil tank	79
005-020_Oil cooler	
4812088174 Oil cooler	81
005-030_Hydraulic block	
4812088199 Hydraulic block	82
005-040_Hydraulic cylinder	
4812088198 Hydraulic cylinder	83
005-050_Hydraulic cylinder	
4812088061 Hydraulic cylinder	84
005-060_Hose set	
4812088228 Hose set	85
006 - Electric system	
Electric system	87
006-010_Instrument panel	
4812088245 Instrument panel	88
006-010-001_Instrument panel	

4812088246A Instrument panel	89
006-010-001-130_Steering	
4812088658 Steering	92
006-010-002_Anti-vandalism protection	
4812088235 Anti-vandalism protection	93
006-010-007_Signs	
4812088300 Signs	94
006-020_Battery box	
4812088139 Battery box	95
006-030_Electrical installation	
4812088152A Electrical installation	97
006-030-001_Warning beacon	
4812088161 Warning beacon	99
006-040_Limit switch	
4812088259 Limit switch	100
007 - Decals	
Decals	101
007-010_Signs	
4812088439 Signs	102
008 - Option	
Option	104
008-010_Twin wheel	
4812061018 Twin wheel	105
008-020_Vibration	
4812061026 Vibration	106
008-020-001_Vibr gearwheel motor	
4812088159 Vibr gearwheel motor	107
008-020-004_Vibr gearwheel motor	
4812088229 Vibr gearwheel motor	109
008-020-005_Hose set	
4812088269 Hose set	111
008-030_Screed extension	
4812088154 Screed extension	112
008-040_Hopper extension	
4812061019 Hopper extension	113
008-050_Scraper	
4812061021 Scraper	114
008-060_Working headlamp	
4812061020 Working headlamp	115
008-070_Tool kit	


4812088044 Tool kit	116
008-080_Filter set 500 h	
4812088544 Filter set 500 h	117
008-090_Filter set 1000 h	
4812088545 Filter set 1000 h	118
Schematics	
F80W_Diagram_EN Electric_hydraulic paver	119

Spare part catalogue F80W




Item	Part No.	Name	Qty	L	C	SN INFO
001	-	Engine	1			
002	-	Steering	1			
003	-	Mechanical	1			
003	-	Mechanical	1			S/N from 4510089 ff.
004	-	Screed	1			
005	-	Hydraulic system	1			
006	-	Electric system	1			
007	-	Accessories and decals	1			
008	-	Option	1			

001 - Engine Engine



Item	Part No.	Name	Qty	L	C	SN INFO
001-010	4812088145	Engine	1			

001-010_Engine 4812088145A Engine**001-010**


Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088142	Motor bracket	1			
2	4812088144	Engine	1			
3	4812088197	Hydraulic pump	1			
4	4812088040	Gas lever	1			
5	4812088553	Accelerator cable	1			
6	4812088193	Holding plate	1			
7	4812088248	Spacer plate	1			
8	4812088208	Tension spring	1			
9	4812088575	Bolt	1			
10	4812088631	Holder	1			SN from 4510111 ff., SN from 3040962 ff.
11	4812088462	Screw	1			
12	4812088554	Adjusting screw	2			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:13 UTC 2026


Item	Part No.	Name	Qty	L	C	SN INFO
13	4812088452	Screw	2			
14	4812088549	Screw	2			
15	4812088628	Screw	1			
16	4812088463	Screw	2			
17	4812088006	Hexagon nut	1			
18	4812088472	Hexagon nut	1			
19	4812088473	Hexagon nut	1			
20	4812088242	Lock washer	1			
21	4812088627	Washer	2			
22	4812088417	Lock washer	2			
23	4812088243	Lock washer	9			
24	4812088244	Lock washer	4			
25	4812088143	Exhaust pipe	1			
26	4812088043	Pipe clip	2			
27	4812088483	Socket head cap screw	8			
28	4812088335	Contact washer	4			
29	4812088209	Washer	2			
30	4812088606	Lock washer	2			
31	4812088358	Air distribution	1			
32	4812088632	Hose clip	1			
006-010-001		Instrument panel	1			

001-010-001_Motor bracket 4812088142 Motor bracket



001-010-001

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088109	Engine bracket	1			
2	4812088108	Engine bracket	1			
3	4812088150	Rubber cushion	4			
4	4812088458	Screw	12			
5	4812088243	Lock washer	12			


001-010-002_Engine 4812088144 Engine**001-010-002**

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088360	Diesel engine	1			
1.01	4812088422	Air filter	1			
1.02	4812088423	Fuel filter	1			
1.03	4812088574	Oil filter	1			
1.04	4812088579	Sealing ring 22x27	1			
1.05	4812088580	Screw plug	1			
1.06	4812088581	Starter	1			
1.07	4812088091	Crankshaft	1			
1.08	4812088576	O-ring	1			
1.09	4812088572	Oil dipstick	1			
1.10	4812088573	Screwed connection	1			
2	4812088041	Coupling	1			
2.01	4812088066	Coupling sleeve	1			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:14 UTC 2026

Item	Part No.	Name	Qty	L	C	SN INFO
2.02	4812088067	Gearwheel	1			
2.03	4812088068	Gearwheel	1			
2.04	4812088065	Coupling housing	1			
6	4812088070	Screwed connection	1			
7	4812088591	Sealing plug	1			
8	4812088458	Screw	1			
9	4812088459	Screw	8			
10	4812088494	Washer	1			
11	4812088243	Lock washer	9			
20	4812088051	Hydr hose	1			


001-010-003_Hydraulic pump 4812088197 Hydraulic pump

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088195	Hydraulic pump	1			
2	4812088589	Screwed connection	2			
3	4812088401	Screwed connection	3			
4	4812088511	L-connection	3			
6	4812088506	Coupling	1			
7	4812088564	Screw coupling	2			
8	4812088585	Screwed connection	1			
9	4812088510	T-connection	1			
10	4812088507	Coupling	1			
11	4812088509	Screwed connection	1			
12	4812088402	Screwed connection	1			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:14 UTC 2026


001-010-031_Air distribution 4812088358 Air distribution




001-010-031

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088357	Air duct	1			
2	4812088355	Strip brush	2			
3	4812088356	Strip brush	2			
4	4812088071	Lock washer	16			
5	4812088448	Screw	8			
6	4812088490	Nut	8			
7	4812088242	Lock washer	4			
8	4812088452	Screw	4			

002 - Drive Drive



Item	Part No.	Name	Qty	L	C	SN INFO
002-010	4812088137	Drive	1			
002-020	4812088122	Wheel	1			


002-010_Drive 4812088137 Drive**002-010**

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088025	Running wheel	2			
2	4812088166	Propulsion engine	1			
2.01	4812088039	Propulsion engine	1			
2.02	4812088401	Screwed connection	2			
2.03	4812088585	Screwed connection	1			
2.04	4812088060	Screwed connection	1			
2.05	4812088510	T-connection	1			
3	4812088348	Wheel support	2			
4	4812088140	Spacer pipe	8			
5	4812088485	Socket head cap screw	32			
6	4812088445	Screw	8			
7	4812088419	Lock washer	32			
8	4812088498	Strain washer	8			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:16 UTC 2026

Item	Part No.	Name	Qty	L	C	SN INFO
9	4812088230	Propulsion engine	1			
9.01	4812088039	Propulsion engine	1			
9.02	4812088401	Screwed connection	2			
9.03	4812088585	Screwed connection	1			
9.04	4812088060	Screwed connection	1			

002-020_Wheel assembly 4812088122 Wheel assembly


Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088292	Wheel support	1			
2	4812088293	Con-rod	1			
3	4812088024	Running wheel	1			
4	4812088347	Guide rods linkage	1			
5	4812088346	Guide rods linkage	1			
6	4812088121	Threaded sleeve	1			
7	4812088759	Flange	2			
7	4812088034	Flange	2			
8	4812088456	Screw	2			
9	4812088452	Screw	2			
10	4812088457	Hex screw	6			
11	4812088594	Screw	1			
12	4812088212	Nut	1			

Refer to Parts Online for the most up to date information. The printed information might be outdated.


Fri Sep 18 06:25:17 UTC 2026

Item	Part No.	Name	Qty	L	C	SN INFO
13	4812088242	Lock washer	2			
14	4812088243	Lock washer	8			
15	4812088003	Washer	2			
16	4812088633	Washer	2			
17	4812088240	Lock washer	2			

003 - Mechanical Mechanical



Item	Part No.	Name	Qty	L	C	SN INFO
003-010	4812088141	Chassis	1			
003-020	4812088136	Hopper	1			
003-030	4812088438	Cover hood	1			
003-040	4812088373	Running board	1			
003-050	4812088155	Reduction sheet	1			


003-010_Chassis 4812088141 Chassis**003-010**

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088125	Frame	1			
2	4812088137	Drive	1			
3	4812088139	Battery box	1			
4	4812088124	Guide	1			
5	4812088135	Guide rod system	1			
6	4812088324	Bolt	2			
7	4812088131	Conveyor belt	1			
8	4812088295	Bumper	1			
9	4812088296	Bumper	1			
10	4812088259	Limit switch	1			
11	4812088374	Cover	1			
12	4812088026	Guide	2			
13	4812088455	Screw	2			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:18 UTC 2026

Item	Part No.	Name	Qty	L	C	SN INFO
14	4812088456	Screw	3			
15	4812088458	Screw	14			
16	4812088472	Hexagon nut	8			
17	4812088243	Lock washer	10			
18	4812088493	Washer	6			
19	4812088243	Lock washer	13			
21	4812088390	Pipe clip	1			
22	4812088389	Pipe clip	1			
23	4812088493	Washer	4			
24	4812088525	Cable tie	2			

003-010-004_Guide 4812088124 Guide**003-010-004**


Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088122	Wheel	1			
2	4812088061	Hydraulic cylinder	1			
3	4812088554	Adjusting screw	1			
4	4812088021	Bushing	2			
5	4812088463	Screw	1			
6	4812088242	Lock washer	1			
7	4812088022	Washer	1			
8	4812088244	Lock washer	1			
9	4812088005	Bulkhead coupling	1			
10	4812088075	Straight connection	1			
11	4812088072	Straight connection	1			
12	4812088618	Conical greasing nipple	1			
13	4812088073	Pipe socket	2			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:19 UTC 2026


Item	Part No.	Name	Qty	L	C	SN INFO
14	4812088074	Clamping sleeve	2			
15	4812088076	Hose	1			
17	4812088517	Plug	1			

003-010-005_Guide rod system 4812088135 Guide rod system



003-010-005

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088134	Hollow profile	1			
2	4812088569	Direction indicator	1			
3	4812088609	Butterfly screw	2			

003-010-007_Conveyor belt 4812088131 Conveyor belt**003-010-007**


Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088009	Drive shaft	1			
2	4812088255	Shaft	1			
3	4812088257	Wear plate	1			
4	4812088010	Chain wheel	1			
5	4812088130	Drive	1			
5	4812088640	Drive	1			Valid to 3000025 & from 4510102 ff.
6	4812088011	Shaft bearing	2			
7	4812088012	Rod with drilled hole	2			
8	4812088126	Protection plate	2			
9	4812088375	Chain guard	1			
10	4812088017	Chain wheel	2			
11	4812088019	Conveyor chain	1			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:20 UTC 2026

Item	Part No.	Name	Qty	L	C	SN INFO
11.01	4812088724	Master link 212A-1H RD/E (C2060H/E)	1			
12	4812088352	Roller chain	1			
12.01	4812088258	Master link	3			
13	4812088034	Flange	2			
13	4812088759	Flange	2			
14	4812088522	Circlip	1			
15	4812088496	Feather key	1			
17	4812088457	Hex screw	6			
18	4812088460	Screw	1			
19	4812088057	Screw	3			
20	4812088472	Hexagon nut	1			
21	4812088244	Lock washer	8			
22	4812088244	Lock washer	9			
23	4812088622	Washer	2			
24	4812088243	Lock washer	9			
25	4812088461	Screw	8			
26	4812088473	Hexagon nut	6			
27	4812088455	Screw	2			
28	4812088463	Screw	3			
29	4812088474	Hexagon nut	4			
30	4812088003	Washer	2			
31	4812088456	Screw	2			
50	4812088200	Fluid motor	1			Valid to 3000025 & from 4510102 ff.

003-010-007-005_Drive 4812088130 Drive




003-010-007-005

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088345	Drive housing	1			
2	4812088013	Drive shaft	1			
3	4812088310	Shaft bearing	2			
4	4812088127	Screw	1			
5	4812088128	Screw	1			
6	4812088014	Rod with drilled hole	2			
7	4812088020	Clamping washer	1			
8	4812088052	Clamping plate	1			
9	4812088056	Clamping plate	1			
10	4812088460	Screw	1			
11	4812088243	Lock washer	7			
12	4812088472	Hexagon nut	1			
13	4812088416	Deep groove ball bearing	2			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:21 UTC 2026

Item	Part No.	Name	Qty	L	C	SN INFO
14	4812088034	Flange	1			
15	4812088617	Feather key	1			
16	4812088243	Lock washer	4			
17	4812088469	Screw	1			
18	4812088626	Hexagon nut	3			
19	4812088461	Screw	4			
20	4812088499	Screw	1			
21	4812088523	Circlip	2			
22	4812088344	Roller chain	1			
22.01	4812088258	Master link	1			
23	4812088600	Hexagon nut	1			
25	4812088625	Hexagon nut	4			
26	4812088200	Fluid motor	1			
26.01	4812088035	Fluid motor	1			
26.02	4812088096	Screw connection	2			
26.03	4812088467	Screw	2			
26.04	4812088215	Washer	2			
26.05	4812088600	Hexagon nut	2			
26.06	4812088585	Screw connection	1			
26.07	4812088512	L-connection	1			
26.08	4812088510	T-connection	1			
26.09	4812088514	Screw connection	1			
27	4812088110	Screw shaft	1			
29	4812088129	End fitting	2			
30	4812088458	Screw	3			
31	4812088015	Chain wheel	1			
32	4812088016	Chain wheel	1			
33	4812088455	Screw	2			
34	4812088244	Lock washer	4			
35	4812088442	Screw	4			
36	4812088620	Sealing ring	2			

003-010-007-005_Drive 4812088640 Drive**003-010-007-005**


Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088641	Housing	1			
3	4812088013	Drive shaft	1			
4	4812088310	Shaft bearing	2			
5	4812088127	Screw	1			
6	4812088128	Screw	1			
7	4812088014	Rod with drilled hole	2			
8	4812088020	Clamping washer	1			
9	4812088052	Clamping plate	1			
10	4812088056	Clamping plate	1			
11	4812088460	Screw	1			
12	4812088243	Lock washer	11			
13	4812088472	Hexagon nut	1			
14	4812088416	Deep groove ball bearing	2			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:21 UTC 2026

Item	Part No.	Name	Qty	L	C	SN INFO
15	4812088034	Flange	1			SN from 3040962 ff.
15	4812088759	Flange	1			
16	4812088617	Feather key	1			
17	4812088469	Screw	1			
18	4812088626	Hexagon nut	3			
19	4812088642	Screw	2			
20	4812088499	Screw	1			
21	4812088523	Circlip	2			
22	4812088344	Roller chain	1			
22.01	4812088258	Master link	1			
23	4812088600	Hexagon nut	1			
24	4812088473	Hexagon nut	2			
25	4812088625	Hexagon nut	4			
27	4812088110	Screw shaft	1			
29	4812088129	End fitting	2			
30	4812088458	Screw	3			
31	4812088015	Chain wheel	1			
32	4812088016	Chain wheel	1			
33	4812088455	Screw	2			
34	4812088244	Lock washer	4			
35	4812088442	Screw	4			
36	4812088620	Sealing ring	2			
003-010-007-050	-	Hydraulic motor				


003-010-007-050 Fluid motor 4812088200 Fluid motor





003-010-007-050

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088035	Fluid motor	1			
2	4812088096	Screwed connection	2			
3	4812088466	Screw	2			
4	4812088215	Washer	2			
6	4812088585	Screwed connection	1			
7	4812088512	L-connection	1			
8	4812088510	T-connection	1			
9	4812088514	Screwed connection	1			

003-020_Hopper 4812088136 Hopper







003-020

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088112	Hopper	1			
2	4812088118	Left side cover	1			
3	4812088120	Right side cover	1			
4	4812088304	Mounting plate	1			
5	4812088113	Mounting plate	1			
8	4812088183	Slide valve	2			
10	4812088234	Guide plate	3			
11	4812088111	Holding plate	1			
16	4812088425	Bumper	1			
21	4812088453	Screw	5			
22	4812088454	Screw	1			
23	4812088456	Screw	10			
24	4812088457	Hex screw	13			
27	4812088463	Screw	9			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:24 UTC 2026


Item	Part No.	Name	Qty	L	C	SN INFO
32	4812088006	Hexagon nut	4			
33	4812088472	Hexagon nut	6			
35	4812088625	Hexagon nut	9			
37	4812088219	Washer	8			
38	4812088243	Lock washer	34			
40	4812088242	Lock washer	4			
41	4812088621	Washer	4			
42	4812088493	Washer	4			
45	4812088627	Washer	18			
50	4812088184	Rod with drilled hole	6			
51	4812088458	Screw	2			
52	4812088006	Hexagon nut	2			
55	4812088101	Clamp body	2			
56	4812088424	Clamp body	5			
57	4812088481	Socket head cap screw	5			
58	4812088608	Serrated lock washer	6			
66	4812088552	Gasket	0.16 5			
67	4812088552	Gasket	0.31 5			
68	4812088492	Washer	1			
70	4812088251	Fuse holder	1			
71	4812088611	Socket head cap screw	2			
72	4812088263	Blowout fuse	1			
73	4812088207	Distributor	1			
74	4812088452	Screw	2			
75	4812088471	Hexagon nut	2			
77	4812088484	Socket head cap screw	1			
78	4812088525	Cable tie	10			
79	4812088037	Oscillation absorber	4			
83	4812088552	Gasket	0.16			
90	4812088288	Plate	2			
91	4812088289	Compression spring	2			
92	4812088278	Connecting plate	2			
93	4812088290	Adjusting lever	1			
94	4812088291	Adjusting lever	1			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:24 UTC 2026


Item	Part No.	Name	Qty	L	C	SN INFO
95	4812088287	Gear lever	2			
97	4812088477	Socket head cap screw	2			
110	4812088341	Bearing housing	2			
111	4812088334	Flange bushing	4			
113	4812088459	Screw	4			
115	4812088429	Washer	6			

003-020-002_Left side cover 4812088118 Left side cover



003-020-002


Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088114	Side cover	1			
4	4812088116	Connecting plate	1			
5	4812088117	Connecting plate	2			
6	4812088425	Bumper	1			
7	4812088621	Washer	1			
9	4812088471	Hexagon nut	8			
10	4812088242	Lock washer	7			
12	4812088400	Truss head screw	6			
20	4812088054	Angle joint	1			
21	4812088115	Bracket	1			

003-020-003_Right side cover 4812088120 Right side cover**003-020-003**

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088119	Side cover	1			
4	4812088116	Connecting plate	2			
5	4812088117	Connecting plate	1			
6	4812088425	Bumper	1			
7	4812088621	Washer	5			
9	4812088471	Hexagon nut	12			
10	4812088242	Lock washer	7			
12	4812088400	Truss head screw	6			
14	4812088082	Document box	1			
15	4812088627	Washer	4			
20	4812088054	Angle joint	1			
21	4812088115	Bracket	1			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:25 UTC 2026


003-030_Cover hood 4812088438 Cover hood**003-030**

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088361	Cover	1			
2	4812088308	Support	1			
3	4812088309	Support	1			
4	4812088437	Plate	1			
5	4812088174	Oil cooler	1			
6	4812088094	Handle	1			
7	4812088551	Lock	1			
8	4812088386	Signal horn	1			
10	4812088414	Spring element	2			
11	4812088413	Washer	2			
13	4812088328	Pipe	1			
15	4812088524	Rubber profile	0.79			
16	4812088093	Screw	2			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:26 UTC 2026

Item	Part No.	Name	Qty	L	C	SN INFO
17	4812088592	Screw	2			
18	4812088089	Screw	1			
19	4812088586	Screw	4			
20	4812088415	Screw	2			
21	4812088489	Nut	2			
22	4812088625	Hexagon nut	2			
23	4812088411	Lock washer	4			
24	4812088602	Washer	2			
25	4812088604	Washer	6			
26	4812088603	Washer	2			
27	4812088596	Hexagon nut	4			
28	4812088410	Lock washer	5			
29	4812088482	Socket head cap screw	4			
31	4812088434	Rope	1			

003-040_Running board 4812088373 Running board**003-040**


Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088372	Foot board	1			
2	4812088364	Switch	1			
3	4812088404	Screw	4			
4	4812088595	Hexagon nut	8			
5	4812088241	Lock washer	8			
6	4812088388	Rear reflector	2			
7	4812088610	Socket head cap screw	4			
8	4812088239	Lock washer	4			
9	4812088605	Washer	2			
10	4812088339	Spacer bushing	2			
11	4812088597	Hexagon nut	2			
12	4812088444	Screw	2			
13	4812088340	Hook	1			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:26 UTC 2026


Item	Part No.	Name	Qty	L	C	SN INFO
19	4812088264	Cable tie	1			
20	4812088627	Washer	3			
21	4812088625	Hexagon nut	1			
22	4812088593	Screw	1			
25	4812088552	Gasket	0.315			

003-050_Reduction sheet 4812088155 Reduction sheet



003-050

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088178	Reduction plate	1			
2	4812088179	Reduction plate	1			
3	4812088412	Cotter spring	4			
4	4812088491	Wing nut	2			
6	4812088338	Protective sleeve	2			
7	4812088333	Holding plate	2			

003 - Mechanical - S/N from 4510089 ff. Mechanical

Item	Part No.	Name	Qty	L	C	SN INFO
003-010	4812088141	Chassis	1			
003-020	4812088136A	Hopper	1			
003-021	4812088644	Hopper weldment	1			
003-022	4812088645	Left side cover	1			
003-023	4812088646	Right side cover	1			
003-030	4812088438A	Covering hood	1			
003-031	4812088647	Cover hood weldment	1			
003-040	4812088373	Running board	1			
003-050	4812088155	Reduction sheet	1			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:27 UTC 2026

Referenced Pages

4812088124 Guide 18

Referenced Pages


4812088135 Guide rod system20

	Referenced Pages
4812088130 Drive	23
4812088640 Drive	25

	Referenced Pages	
4812088200 Fluid motor		27
	Referenced Pages	
4812088131 Conveyor belt		21


Referenced Pages

4812088141 Chassis 16


003-020_Hopper 4812088136A Hopper**003-020**

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:29 UTC 2026



003-020



003-020

Item	Part No.	Name	Qty	L	C	SN INFO
4	4812088304	Mounting plate	1			
5	4812088113	Mounting plate	1			
8	4812088183	Slide valve	2			
10	4812088234	Guide plate	3			
11	4812088111	Holding plate	1			
16	4812088425	Bumper	1			
21	4812088453	Screw	5			
22	4812088454	Screw	1			
23	4812088456	Screw	10			
24	4812088457	Hex screw	13			
27	4812088463	Screw	9			
32	4812088006	Hexagon nut	4			
33	4812088472	Hexagon nut	6			
35	4812088625	Hexagon nut	9			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:30 UTC 2026


Item	Part No.	Name	Qty	L	C	SN INFO
37	4812088219	Washer	8			
38	4812088243	Lock washer	34			
40	4812088242	Lock washer	4			
41	4812088621	Washer	4			
42	4812088493	Washer	4			
45	4812088627	Washer	18			
50	4812088184	Rod with drilled hole	6			
51	4812088458	Screw	2			
52	4812088006	Hexagon nut	2			
56	4812088424	Clamp body	7			
57	4812088481	Socket head cap screw	5			
58	4812088608	Serrated lock washer	6			
66	4812088552	Gasket	0.16 5			
67	4812088552	Gasket	0.31 5			
68	4812088492	Washer	1			
70	4812088251	Fuse holder	1			
71	4812088611	Socket head cap screw	2			
72	4812088263	Blowout fuse	1			
73	4812088207	Distributor	1			
74	4812088452	Screw	2			
75	4812088471	Hexagon nut	2			
77	4812088484	Socket head cap screw	1			
78	4812088525	Cable tie	10			
79	4812088037	Oscillation absorber	4			
83	4812088552	Gasket	0.16			
90	4812088288	Plate	2			
91	4812088289	Compression spring	2			
92	4812088278	Connecting plate	2			
93	4812088290	Adjusting lever	1			
94	4812088291	Adjusting lever	1			
95	4812088287	Gear lever	2			
97	4812088477	Socket head cap screw	2			
110	4812088341	Bearing housing	2			
111	4812088334	Flange bushing	4			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:30 UTC 2026

Item	Part No.	Name	Qty	L	C	SN INFO
113	4812088459	Screw	4			
115	4812088429	Washer	6			
003-021	-	Hopper	1			
003-022	-	Left side cover	1			
003-023	-	Right side cover	1			


003-021_Hopper weldment 4812088644 Hopper weldment




003-021

Item	Part No.	Name	Qty	L	C	SN INFO
0	4812088644	Hopper weldment	1			

003-022_Left side cover 4812088645 Left side cover




Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088648	Cover	1			
4	4812088116	Connecting plate	1			
5	4812088117	Connecting plate	2			
6	4812088425	Bumper	1			
7	4812088621	Washer	1			
9	4812088471	Hexagon nut	8			
10	4812088242	Lock washer	7			
12	4812088400	Truss head screw	6			
20	4812088054	Angle joint	1			
21	4812088115	Bracket	1			

003-023_Right side cover 4812088646 Right side cover

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088649	Cover	1			
4	4812088116	Connecting plate	2			
5	4812088117	Connecting plate	1			
6	4812088425	Bumper	1			
7	4812088621	Washer	5			
9	4812088471	Hexagon nut	12			
10	4812088242	Lock washer	7			
12	4812088400	Truss head screw	6			
14	4812088082	Document box	1			
15	4812088627	Washer	4			
20	4812088054	Angle joint	1			
21	4812088115	Bracket	1			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:31 UTC 2026

003-030_Cover hood 4812088438A Cover hood**003-030**


Item	Part No.	Name	Qty	L	C	SN INFO
2	4812088308	Support	1			
3	4812088309	Support	1			
4	4812088437	Plate	1			
5	4812088174	Oil cooler	1			
6	4812088094	Handle	1			
7	4812088551	Lock	1			
8	4812088386	Signal horn	1			
10	4812088414	Spring element	2			
11	4812088413	Washer	2			
13	4812088328	Pipe	1			
15	4812088524	Rubber profile	0.79			
16	4812088093	Screw	2			
17	4812088650	Screw	2			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:32 UTC 2026

Item	Part No.	Name	Qty	L	C	SN INFO
18	4812088651	Screw	1			
19	4812088462	Screw	4			
20	4812088415	Screw	2			
21	4812088489	Nut	2			
22	4812088625	Hexagon nut	2			
23	4812088244	Lock washer	4			
24	4812088242	Lock washer	2			
25	4812088494	Washer	6			
26	4812088216	Washer	2			
27	4812088472	Hexagon nut	4			
28	4812088243	Lock washer	5			
29	4812088482	Socket head cap screw	4			
31	4812088434	Rope	1			
003-031	-	Cover	1			

003-031_Cover hood weldment 4812088647 Cover hood weldment



003-031

Item	Part No.	Name	Qty	L	C	SN INFO
0	4812088647	Cover hood weldment	1			


Referenced Pages

4812088373 Running board37


Referenced Pages


4812088155 Reduction sheet39

004 - Screed Screed



Item	Part No.	Name	Qty	L	C	SN INFO
004-010	4812088371	Smoothing screed	1			
004-020	4812088367	Heating	1			
004-030	4812088087	Adaptor	1			
004-040	4812088286	Copying system	1			Valid upto 4510236.
004-050	4812088270	Without vibration	1			

004-010_Smoothing screed 4812088371 Smoothing screed**004-010**



Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088368	Frame	1			
2	4812088369	Frame	1			
3	4812088370	Frame	1			
4	4812088170	Support	1			
5	4812088169	Support	1			
6	4812088172	Side plate	1			
7	4812088171	Side plate	1			
8	4812088149	Rubber cushion	1			
9	4812088148	Longitudinal beam	1			
10	4812088032	Con-rod	1			
11	4812088033	Con-rod	1			
12	4812088173	Pull rod	2			
13	4812088331	Cylinder support	1			
14	4812088332	Cylinder support	1			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:35 UTC 2026

Item	Part No.	Name	Qty	L	C	SN INFO
15	4812088349	Bolt	4			
16	4812088366	Shaft	2			
16.02	4812088107	Handle	1			
16.03	4812088614	Spring pin	1			
16.04	4812088365	Shaft	1			
16.05	4812088218	Washer	2			
16.06	4812088615	Spring pin	1			
18	4812088029	Spacer bushing	2			
19	4812088045	Plate	2			
20	4812088055	Guide rod	2			
21	4812088027	Bushing	2			
22	4812088028	Bushing	2			
23	4812088201	Wear plate	1			
24	4812088046	Plate	1			
25	4812088058	Rod end bearing	1			
26	4812088059	Rod end bearing	1			
27	4812088031	Threaded sleeve	1			
30	4812088412	Cotter spring	2			
31	4812088395	Greasing nipple	2			
32	4812088495	Split-pin	4			
33	4812088393	Blind rivet	8			
34	4812088427	Support	2			
36	4812088231	Guide plate	2			
37	4812088160	Guide	2			
38	4812088232	Support	1			
39	4812088233	Support	1			
40	4812088175	End plate	2			
41	4812088428	Spacer bushing	2			
42	4812088030	Bolt	2			
48	4812088466	Screw	6			
49	4812088481	Socket head cap screw	6			
50	4812088463	Screw	6			
51	4812088462	Screw	16			
55	4812088487	Hexagon nut	8			
56	4812088451	Screw	4			


Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:35 UTC 2026

Item	Part No.	Name	Qty	L	C	SN INFO
57	4812088494	Washer	2			
58	4812088242	Lock washer	12			
59	4812088492	Washer	4			
60	4812088446	Screw	2			
61	4812088613	Screw	2			
62	4812088447	Screw	2			
63	4812088588	Screw	2			
64	4812088464	Screw	2			
65	4812088465	Screw	4			
66	4812088461	Screw	2			
67	4812088452	Screw	4			
68	4812088457	Hex screw	2			
69	4812088212	Nut	2			
70	4812088239	Lock washer	8			
71	4812088600	Hexagon nut	2			
73	4812088244	Lock washer	30			
74	4812088243	Lock washer	2			
75	4812088217	Washer	2			
76	4812088418	Lock washer	6			
77	4812088627	Washer	34			
78	4812088493	Washer	2			
81	4812088262	Hydraulic cylinder	2			
84	4812088497	Strain washer	8			
85	4812088441	Screw	8			
86	4812088189	Plate	1			
87	4812088194	Plate	1			
88	4812088585	Screw connection	2			
89	4812088301	Plate	1			
90	4812088449	Screw	2			
91	4812088071	Lock washer	2			
92	4812088409	Edge protection profile	0.66			
93	4812088488	Hexagon nut	1			
94	4812088337	Screw connection	2			
95	4812088517	Plug	6			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:35 UTC 2026


004-020_Heating 4812088367 Heating**004-020**

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088162	Automatic ignition	1			
2	4812088164	Burner	1			
6	4812088620	Sealing ring	3			
8	4812088455	Screw	3			
10	4812088243	Lock washer	8			
11	4812088476	Socket head cap screw	15			
12	4812088214	Washer	30			
14	4812088211	Nut	15			
17	4812088379	Cable	1			
18	4812088380	Cable	2			
20	4812088457	Hex screw	4			
21	4812088472	Hexagon nut	4			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:35 UTC 2026


Item	Part No.	Name	Qty	L	C	SN INFO
100	4812088426	Holder	1			SN from 3000025 to 3004326 & from 4510001 ff.
110	4812088660	Holder	1			SN from 3000025 to 3004326 & from 4510001 ff.

004-020-001_Automatic ignition 4812088162 Automatic ignition**004-020-001**

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088359	Temperature sensor	1			
2	4812088377	Spark plug	3			
3	4812088378	Valve	2			
3	4812088776	Valve	2			SN from 3075018 ff.
4	4812088376	Ignition box	3			
5	4812088556	Screwed connection	1			
7	4812088420	Screwed connection	1			
8	4812088505	Reduction	1			
9	4812088620	Sealing ring	4			
10	4812088305	Foil	1			
11	4812088306	Foil	1			
12	4812088307	Foil	1			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:36 UTC 2026

004-020-002_Burner 4812088164 Burner**004-020-002**


Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088302	Valve block	1			
1.01	4812088049	Valve block	1			
1.02	4812088560	Screwed connection	1			
1.03	4812088559	Dummy plug	1			
1.04	4812088556	Screwed connection	3			
1.05	4812088620	Sealing ring	3			
1.06	4812088637	Banjo elbow fitting	1			Valid to 3000025 & from 4510089 ff.
2	4812088062	Gas nozzle	3			
2.01	4812088100	Gas nozzle	1			
2.02	4812088583	Male stud coupling body	1			
2.03	4812088620	Sealing ring	1			
2.04	4812088050	Assembly	1			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:36 UTC 2026

Item	Part No.	Name	Qty	L	C	SN INFO
3	4812088436	Valve	1			
3.01	4812088548	Gas pressure regulator	1			
3.02	4812088550	Manometer	1			
3.03	4812088384	Safety valve	1			
3.04	4812088102	Screw connection	1			
3.05	4812088103	Screw connection	1			
3.06	4812088104	Screw connection	1			
4	4812088557	Screw connection	1			
5	4812088638	Gas hose	2			
6	4812088639	Gas hose	2			
8	4812088069	Lashing belt	1			
9	4812088471	Hexagon nut	2			
10	4812088242	Lock washer	2			
11	4812088209	Washer	2			
12	4812088441	Screw	2			
13	4812088417	Lock washer	2			
20	4812088742	Reduction	1			SN from 3004327 ff.


004-020-100_Holder 4812088426 Holder



004-020-100

Item	Part No.	Name	Qty	L	C	SN INFO
0	4812088426	Holder	1			


004-020-110_Holder 4812088660 Holder



004-020-110

Item	Part No.	Name	Qty	L	C	SN INFO
0	4812088660	Holder	1			


004-030_Adaptor 4812088087 Adaptor



004-030


Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088085	Screwed connection	1			
2	4812088086	Washer	1			
3	4812088084	Union nut	1			

004-040_Copying system 4812088286 Copying system



004-040

Item	Part No.	Name	Qty	L	C	SN INFO
10	4812088285	Left carrier pulley	1			
20	4812088284	Right carrier pulley	1			
30	4812088622	Washer	6			
40	4812088239	Lock washer	6			
50	4812088468	Screw	6			

004-040-010_Left carrier pulley 4812088285 Left carrier pulley**004-040-010**


Item	Part No.	Name	Qty	L	C	SN INFO
10	4812088282	Angle plate	1			
20	4812088351	Roller holder	1			
30	4812088283	Hood holding device	1			
40	4812088276	Spindle	1			
50	4812088275	Star grip	1			
70	4812088216	Washer	1			
80	4812088281	Wheel	1			
90	4812088350	Bushing	1			
100	4812088443	Screw	1			
110	4812088625	Hexagon nut	1			
120	4812088244	Lock washer	2			
130	4812088277	Plain bearing bushing	2			
140	4812088099	Washer	4			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:39 UTC 2026

Item	Part No.	Name	Qty	L	C	SN INFO
150	4812088628	Screw	2			
160	4812088599	Hexagon nut	2			
170	4812088243	Lock washer	4			
180	4812088598	Hexagon nut	3			
190	4812088601	Hexagon nut	1			

004-040-020_Right carrier pulley 4812088284 Right carrier pulley



004-040-020


Item	Part No.	Name	Qty	L	C	SN INFO
10	4812088282	Angle plate	1			
20	4812088351	Roller holder	1			
30	4812088283	Hood holding device	1			
40	4812088276	Spindle	1			
50	4812088275	Star grip	1			
70	4812088216	Washer	1			
80	4812088281	Wheel	1			
90	4812088350	Bushing	1			
100	4812088443	Screw	1			
110	4812088625	Hexagon nut	1			
120	4812088244	Lock washer	2			
130	4812088277	Plain bearing bushing	2			
140	4812088099	Washer	4			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:40 UTC 2026

Item	Part No.	Name	Qty	L	C	SN INFO
150	4812088628	Screw	2			
160	4812088599	Hexagon nut	2			
170	4812088243	Lock washer	4			
180	4812088598	Hexagon nut	3			
190	4812088601	Hexagon nut	1			


004-050_Without vibration 4812088270 Without vibration




004-050

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088515	Sealing plug	3			
2	4812088504	Union nut	3			
003-010-007-005		Drive	1			
005-030		Hydraulic block	1			

005 - Hydraulic system Hydraulic system



Item	Part No.	Name	Qty	L	C	SN INFO
005-010	4812088188	Hydraulic oil tank	1			
005-020	4812088174	Oil cooler	1			
005-030	4812088199	Hydraulic block	1			
005-040	4812088198	Hydraulic cylinder	1			
005-050	4812088061	Hydraulic cylinder	1			
005-060	4812088228	Hose set	1			

005-010_Hydraulic oil tank 4812088188 Hydraulic oil tank

005-010


Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088190	Hydraulic oil tank	1			
2	4812088077	Return-suction filter	1			
2.01	4812088088	Filter set	1			
2.02	4812088079	O-ring	1			
2.03	4812088078	O-ring	1			
3	4812088106	Breather filter	1			
4	4812088383	Inspection glass	1			
5	4812088485	Socket head cap screw	2			
6	4812088419	Lock washer	2			
7	4812088590	Reducing adapter	1			
8	4812088589	Screw connection	1			
9	4812088619	Screw plug	1			
10	4812088394	Sealing ring	1			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:42 UTC 2026

Item	Part No.	Name	Qty	L	C	SN INFO
11	4812088204	Screw connection	1			
12	4812088478	Socket head cap screw	1			
13	4812088607	Serrated lock washer	1			
14	4812088090	Screw connection	1			
15	4812088440	Screw connection	1			
16	4812088456	Screw	3			
17	4812088243	Lock washer	3			


005-020_Oil cooler 4812088174 Oil cooler



005-020


Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088181	Retaining plate	1			
2	4812088343	Oil-air cooler	1			
3	4812088342	Temperature switch	1			
4	4812088396	Sealing ring	1			
5	4812088421	Screwed connection	2			
6	4812088480	Socket head cap screw	4			
7	4812088243	Lock washer	4			
8	4812088472	Hexagon nut	4			

005-030_Hydraulic block 4812088199 Hydraulic block



005-030

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088196	Hydraulic block	1			
1.01	4812088667	Magnetic coil	1			
1.02	4812088668	Magnetic coil	1			
2	4812088457	Hex screw	4			
3	4812088243	Lock washer	4			
4	4812088511	L-connection	1			
5	4812088210	Washer	4			
6	4812088512	L-connection	1			
7	4812088391	Manometer connection	1			
8	4812088098	Pressure switch	1			
9	4812088510	T-connection	1			


005-040_Hydraulic cylinder 4812088198 Hydraulic cylinder**005-040**

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088260	Hydraulic cylinder	1			
1.01	4812088395	Greasing nipple	1			
2	4812088616	Sealing ring	1			
3	4812088036	Bleeder screw	1			
4	4812088446	Screw	1			
5	4812088212	Nut	2			
6	4812088240	Lock washer	1			
7	4812088206	Screw	1			
8	4812088513	Screw	1			
10	4812088517	Plug	1			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:44 UTC 2026


005-050_Hydraulic cylinder 4812088061 Hydraulic cylinder



005-050

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088261	Hydraulic cylinder	1			
1.01	4812088555	Sealing kit	1			
2	4812088023	Washer	1			
3	4812088575	Bolt	1			
4	4812088558	Hollow screw	2			
5	4812088620	Sealing ring	4			
6	4812088461	Screw	1			
7	4812088244	Lock washer	1			
8	4812088470	Screw	1			
10	4812088212	Nut	1			
002-020		Wheel	1			

005-060_Hose set 4812088228 Hose set



005-060


Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088503	Hydr hose	1			
2	4812088220	Hydr hose	1			
3	4812088502	Hydr hose	1			
4	4812088265	Hydr hose	1			
5	4812088221	Hydr hose	1			
6	4812088222	Hydr hose	1			
7	4812088266	Hydr hose	1			
8	4812088267	Hydr hose	1			
9	4812088223	Hydr hose	1			
10	4812088224	Hydr hose	1			
11	4812088225	Hydr hose	1			
12	4812088226	Hydr hose	1			
13	4812088325	Hydr hose	1			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:45 UTC 2026


Item	Part No.	Name	Qty	L	C	SN INFO
14	4812088317	Hydr hose	1			
17	4812088318	Hydr hose	1			
18	4812088319	Hydr hose	1			
19	4812088236	Hydr hose	1			
20	4812088316	Hydr hose	1			
21	4812088322	Hydr hose	1			
22	4812088238	Hydr hose	1			
23	4812088314	Hydr hose	1			
24	4812088315	Hydr hose	1			
25	4812088326	Hydr hose	1			
26	4812088227	Hydr hose	1			
27	4812088268	Hydr hose	1			
28	4812088327	Hydr hose	1			
32	4812088237	Hydr hose	1			
33	4812088320	Hydr hose	1			
34	4812088321	Hydr hose	1			

006 - Electric system Electric system



Item	Part No.	Name	Qty	L	C	SN INFO
006-010	4812088245	Instrument panel	1			
006-020	4812088139	Battery box	1			
006-030	4812088152	Warning beacon	1			
006-030	4812088152A	Warning beacon	1			SN from 4510111 ff.
006-040	4812088259	Limit switch	1			


006-010_Instrument panel 4812088245 Instrument panel



006-010

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088246	Instrument panel	1			
1	4812088246A	Instrument panel	1			SN from 4510111 ff.
2	4812088235	Anti-vandalism protection	1			
3	4812088298	Journal	1			
4	4812088482	Socket head cap screw	1			
5	4812088493	Washer	1			
6	4812088273	Flange bushing	2			
7	4812088300	Signs	1			

006-010-001_Instrument panel 4812088246A Instrument panel



006-010-001

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088247	Cover plate	1			
12	4812088242	Lock washer	4			
13	4812088405	Screw	4			
21	4812088243	Lock washer	3			
22	4812088458	Screw	3			
29	4812088330	Direction indicator	1			
30	4812088329	Foil	1			
31	4812088105	Washer	4			
32	4812088497	Strain washer	2			
33	4812088006	Hexagon nut	2			
34	4812088493	Washer	1			
35	4812088554	Adjusting screw	1			
36	4812088092	Accelerator cable	1			

Fri Sep 18 06:25:47 UTC 2026


Item	Part No.	Name	Qty	L	C	SN INFO
37	4812088471	Hexagon nut	2			
39	4812088208	Tension spring	1			
40	4812088562	Socket	1			
50	4812088623	Sleeve body	1			
51	4812088624	Screw	1			
60	4812088252	Plug board	1			
61	4812088205	Relay module	2			
62	4812088249	Relay	9			
63	4812088475	Socket head cap screw	6			
64	4812088213	Washer	6			
65	4812088210	Washer	1			
66	4812088418	Lock washer	1			
67	4812088459	Screw	1			
70	4812088516	Switch	1			
80	4812088385	Ignition lock	1			
80.01	4812088547	Key	1			
90	4812088001	Emergency push button	1			
100	4812088630	Joystick	1			
104	4812088518	Fuse	1			
105	4812088382	Blowout fuse	1			
106	4812088398	Blowout fuse	1			
107	4812088397	Blowout fuse	3			
108	4812088097	Blowout fuse	1			
109	4812088399	Blowout fuse	1			
110	4812088561	Potentiometer	1			
111	4812088250	Display unit	1			
120	4812088167	Handle guard	8			
123	4812088253	Toggle switch	4			
124	4812088271	Toggle switch	2			
125	4812088254	Toggle switch	2			
128	4812088524	Rubber profile	0.56			
129	4812088524	Rubber profile	0.56			
130	4812088192	Steering wheel	1			
130.01	4812088279	End cap	1			
130.02	4812088280	Rotary handle	1			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:47 UTC 2026


Item	Part No.	Name	Qty	L	C	SN INFO
130	4812088658	Steering	1			
131	4812088191	Steering hydraulics	1			
132	4812088417	Lock washer	4			
133	4812088634	Socket head cap screw	4			
134	4812088182	Spacer sleeve	2			
135	4812088486	Feather key	1			
137	4812088492	Washer	4			

006-010-001-130_Steering 4812088658 Steering



Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088192	Steering wheel	1			
1.02	4812088280	Rotary handle	1			
2	4812088659	Cover	1			


006-010-002_Anti-vandalism protection 4812088235 Anti-vandalism protection



006-010-002

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088274	Cover	1			
3	4812088524	Rubber profile	0.45 5			
4	4812088004	Handgrip	1			
5	4812088479	Socket head cap screw	2			
6	4812088406	Blind rivet nut	2			
7	4812088524	Rubber profile	0.44 5			


006-010-007_Signs 4812088300 Signs



006-010-007

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088539	Plate	1			
2	4812088540	Plate	1			
3	4812088297	Foil	1			

006-020_Battery box 4812088139 Battery box



006-020


Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088138	Battery box	1			
2	4812088132	Mounting plate	1			
3	4812088133	Battery box cover	1			
4	4812088038	Bent-lever closure	1			
5	4812088053	Bent-lever closure	1			
6	4812088243	Lock washer	1			
7	4812088146	Hinge	2			
8	4812088071	Lock washer	8			
9	4812088493	Washer	1			
10	4812088643	Blind rivet	4			
11	4812088490	Nut	8			
12	4812088628	Screw	1			
14	4812088063	Switch	1			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:50 UTC 2026

Item	Part No.	Name	Qty	L	C	SN INFO
14	4812088387	Battery isolation switch	1			
15	4812088453	Screw	2			
16	4812088242	Lock washer	2			
17	4812088471	Hexagon nut	2			
18	4812088407	Screw	8			

006-030_Electrical installation 4812088152A Electrical installation



006-030


Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088161	Warning beacon	1			
2	4812088007	Starter battery	1			
3	4812088362	Battery cable	1			
6	4812088083	Warning buzzer	1			
7	4812088243	Lock washer	2			
8	4812088457	Hex screw	2			
9	4812088472	Hexagon nut	2			
10	4812088243	Lock washer	2			
12	4812088546	Control unit	1			
13	4812088242	Lock washer	4			
14	4812088453	Screw	4			
16	4812088390	Pipe clip	1			
30	4812088381	Cable harness	1			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:50 UTC 2026

Item	Part No.	Name	Qty	L	C	SN INFO
30	4812088629	Cable harness	1			SN from 4510111 ff.
006-020		Battery box	1			


006-030-001_Warning beacon 4812088161 Warning beacon



006-030-001

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088147	Rod	1			
2	4812088081	Attachment	1			
3	4812088363	Cable	1			
3.01	4812088408	Plug	1			
4	4812088657	Revolving light	1			
5	4812088609	Butterfly screw	1			

006-040_Limit switch 4812088259 Limit switch




006-040

Item	Part No.	Name	Qty	L	C	SN INFO
10	4812088353	Attachment	1			
20	4812088336	Material button	1			
30	4812088018	Gear lever	1			
40	4812088354	Holder	1			
50	4812088064	Sensor	1			
60	4812088612	Socket head cap screw	4			
70	4812088457	Hex screw	2			
80	4812088452	Screw	1			
90	4812088071	Lock washer	4			
100	4812088472	Hexagon nut	1			
110	4812088628	Screw	1			
120	4812088243	Lock washer	3			
130	4812088456	Screw	1			

Refer to Parts Online for the most up to date information. The printed information might be outdated.


Fri Sep 18 06:25:51 UTC 2026

007 - Decals Decals



Item	Part No.	Name	Qty	L	C	SN INFO
007-010	4812088439	Signs	1			

007-010_Signs 4812088439 Signs




007-010

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088543	Plate	2			
3	4812088528	Symbol	1			
4	4812088163	Foil	4			
5	4812088534	Symbol	2			
6	4812088529	Symbol	1			
7	4812088527	Symbol	4			
8	4812088536	Symbol	4			
9	4812088532	Symbol	1			
11	4812088537	Plate	1			
12	4812088577	Foil	1			
14	4812088323	Foil	2			
15	4812088000	Warning film	1			
16	4812088535	Symbol	1			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:53 UTC 2026

Item	Part No.	Name	Qty	L	C	SN INFO
17	4812088531	Symbol	1			
18	4812088571	Foil	3			
19	4812088570	Foil	1			
20	4812088578	Foil	1			
21	4812088002	Warning film	1			
22	4812088299	Foil	1			
23	4812088533	Symbol	2			
24	4812088530	Symbol	1			
25	4812088526	Symbol	1			
26	4812088538	Plate	1			
27	4812088541	Plate	1			
28	4812088542	Plate	1			


008 - Option Option

Item	Part No.	Name	Qty	L	C	SN INFO
008-010	4812061018	Twin wheel	1			
008-020	4812061026	Vibration	1			Upto S/N 4510158.
008-020	4812061026A	Vibration	1			Valid from SN 4510159, ff.
008-030	4812088154	Screed extension	1			
008-040	4812061019	Hopper extension	1			
008-050	4812061021	Scraper	1			
008-060	4812061020	Working headlamp	1			
008-070	4812088044	Pipe clip	1			
008-080	4812088544	Filter set 500 h	1			
008-090	4812088545	Filter set 1000 h	1			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:54 UTC 2026


008-010_Twin wheel 4812061018 Twin wheel



008-010


Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088042	Support	2			
2	4812088025	Running wheel	2			
3	4812088485	Socket head cap screw	24			
4	4812088419	Lock washer	24			
10	4812088272	Protection plate	2			
11	4812088243	Lock washer	6			
12	4812088458	Screw	6			
13	4812088472	Hexagon nut	6			
14	4812088243	Lock washer	6			

008-020_Vibration 4812061026 Vibration



008-020

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088159	Vibr gearwheel motor	1			
2	4812088456	Screw	8			
3	4812088243	Lock washer	8			
4	4812088229	Vibr gearwheel motor	1			
5	4812088269	Hose set	1			
6	4812088430	Guard	1			
7	4812088431	Guard	1			
8	4812088432	Guard	3			
004-010		Smoothing screed	1			


008-020-001_Vibr gearwheel motor 4812088159 Vibr gearwheel motor**008-020-001**

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088158	Gear motor	1			
2	4812088156	Driver	1			
2	4812088433	Driver	1			Valid from SN 4510050, ff.
3	4812088157	Bearing	1			
3	4812088435	Bearing	1			Valid from SN 4510050, ff.
4	4812088151	Unbalance flywheel	1			
6	4812088584	Socket head cap screw	4			
7	4812088587	Deep groove ball bearing	1			
8	4812088403	Screwed connection	1			
9	4812088392	Circlip	1			
10	4812088479	Socket head cap screw	4			
11	4812088242	Lock washer	4			
12	4812088165	Flange	2			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:56 UTC 2026

Item	Part No.	Name	Qty	L	C	SN INFO
13	4812088095	Screw connection	2			
14	4812088243	Lock washer	1			

008-020-004_Vibr gearwheel motor 4812088229 Vibr gearwheel motor**008-020-004**


Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088158	Gear motor	1			
2	4812088156	Driver	1			
2	4812088433	Driver	1			Valid from SN 4510050, ff.
3	4812088157	Bearing	1			
3	4812088435	Bearing	1			Valid from SN 4510050, ff.
4	4812088151	Unbalance flywheel	1			
6	4812088584	Socket head cap screw	4			
7	4812088587	Deep groove ball bearing	1			
8	4812088403	Screwed connection	1			
9	4812088392	Circlip	1			
10	4812088479	Socket head cap screw	4			
11	4812088242	Lock washer	4			
12	4812088165	Flange	2			

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Sep 18 06:25:56 UTC 2026

Item	Part No.	Name	Qty	L	C	SN INFO
13	4812088095	Screw connection	2			
14	4812088508	L-connection	1			
15	4812088243	Lock washer	1			


008-020-005_Hose set 4812088269 Hose set



008-020-005

Item	Part No.	Name	Qty	L	C	SN INFO
15	4812088312	Hydr hose	1			
16	4812088313	Hydr hose	1			
29	4812088501	Hydr hose	1			
29	4812088756	Hydr hose	1			Valid from SN 3040962, ff.
30	4812088500	Hydr hose	1			
30	4812088757	Hydr hose	1			Valid from SN 3040962, ff.
31	4812088311	Hydr hose	1			


008-030_Screed extension 4812088154 Screed extension



008-030

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088176	Screed extension	1			
2	4812088177	Screed extension	1			
3	4812088203	Screw	1			
4	4812088202	Screw	1			
5	4812088622	Washer	8			
6	4812088239	Lock washer	8			
7	4812088466	Screw	8			


008-040_Hopper extension 4812061019 Hopper extension



008-040

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088186	Funnel plate	1			
2	4812088187	Funnel plate	1			


008-050_Scraper 4812061021 Scraper



008-050

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088168	Scraper	1			
2	4812088450	Screw	4			
3	4812088071	Lock washer	4			


008-060_Working headlamp 4812061020 Working headlamp



008-060

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088256	Worklamp	1			


008-070_Tool kit 4812088044 Tool kit



008-070

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088565	Toolbag	1			
2	4812088566	Screwdriver	1			
3	4812088568	Open-ended spanner	1			
4	4812088520	Key	1			
6	4812088521	Key	1			
7	4812088567	Socket wrench	1			


008-080_Filter set 500 h 4812088544 Filter set 500 h



008-080

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088423	Fuel filter	1			
2	4812088422	Air filter	1			

008-090_Filter set 1000 h 4812088545 Filter set 1000 h



008-090

Item	Part No.	Name	Qty	L	C	SN INFO
1	4812088423	Fuel filter	1			
2	4812088422	Air filter	1			
3	4812088088	Filter set	1			

Electric & Hydraulic

Asphalt paver wheeled

F80W


Hatz



Machine wiring diagram

Legend:

A1 Diesel engine	S6 Brake pressure switch
A2 Control unit Bodas RC	S7 Feed switch
A3 Display	S8 Foot switch
A4 Drive lever	S9 Horn button
A5 Diagnostic socket	S10 Paving width switch left
A6 Screed gas heating controller 1 (left)	S11 Paving width switch right
A7 Screed gas heating controller 2 (middle)	S12 Screed lift/lower switch
A8 Screed gas heating controller 3 (right)	S13 Vibration switch
F1 - F8 Fuses	S14 Screed heating switch
F9 Main fuse	S15 Conveyor direction switch
F10 Starter fuse	S16 Mode selector
G1 Battery	S17 Transport/operating mode switch
H1 Warning beacon	S18 Screed temperature switch
H2 Auger lighting	Y1 Conveyor/auger right
I1 Burner ignition (left)	Y2 Conveyor/auger reverse
I2 Burner ignition (middle)	Y3 Screed extension left ejection
I3 Burner ignition (right)	Y4 Screed extension left retraction
K1 - K6 Relay	Y5 Screed extension right retraction
K10 Relay	Y6 Screed extension right ejection
M1 Oil cooling fan	Y7 Brake release
P1 Horn	Y8 Screed floating position
P2 Reverse beeper	Y9 Screed release
R1 Speed control POT wiper	Y10 Screed lift
R2 Pump angle POT wiper	Y11 Screed vibration
R3 - R6 Resistor	Y12 Drive pump forward
S1 Disconnecter	Y13 Drive pump back ward
S2 Emergency brake button	Y14 Solenoid of the gas shut-off valve
S3 Ignition switch	Y15 Solenoid of the gas shut-off valve
S5 Oil temperature switch	



Machine wiring diagram


Legend:

A1 Diesel engine	S6 Brake pressure switch
A2 Control unit Bodas RC	S7 Feed switch
A3 Display	S8 Foot switch
A4 Drive lever	S9 Horn button
A5 Diagnostic socket	S10 Paving width switch left
A6 Screed gas heating controller 1 (left)	S11 Paving width switch right
A7 Screed gas heating controller 2 (middle)	S12 Screed lift/lower switch
A8 Screed gas heating controller 3 (right)	S13 Vibration switch
F1 - F8 Fuses	S14 Screed heating switch
F9 Main fuse	S15 Conveyor direction switch
F10 Starter fuse	S16 Mode selector
G1 Battery	S17 Transport/operating mode switch
H1 Warning beacon	S18 Screed temperature switch
H2 Auger lighting	Y1 Conveyor/auger right
I1 Burner ignition (left)	Y2 Conveyor/auger reverse
I2 Burner ignition (middle)	Y3 Screed extension left ejection
I3 Burner ignition (right)	Y4 Screed extension left retraction
K1 - K6 Relay	Y5 Screed extension right retraction
K10 Relay	Y6 Screed extension right ejection
M1 Oil cooling fan	Y7 Brake release
P1 Horn	Y8 Screed floating position
P2 Reverse beeper	Y9 Screed release
R1 Speed control POT wiper	Y10 Screed lift
R2 Pump angle POT wiper	Y11 Screed vibration
R3 - R6 Resistor	Y12 Drive pump forward
S1 Disconnecter	Y13 Drive pump back ward
S2 Emergency brake button	Y14 Solenoid of the gas shut-off valve
S3 Ignition switch	Y15 Solenoid of the gas shut-off valve
S5 Oil temperature switch	

Machine wiring diagram

Legend:

A1 Diesel engine	S6 Brake pressure switch
A2 Control unit Bodas RC	S7 Feed switch
A3 Display	S8 Foot switch
A4 Drive lever	S9 Horn button
A5 Diagnostic socket	S10 Paving width switch left
A6 Screed gas heating controller 1 (left)	S11 Paving width switch right
A7 Screed gas heating controller 2 (middle)	S12 Screed lift/lower switch
A8 Screed gas heating controller 3 (right)	S13 Vibration switch
F1 - F8 Fuses	S14 Screed heating switch
F9 Main fuse	S15 Conveyor direction switch
F10 Starter fuse	S16 Mode selector
G1 Battery	S17 Transport/operating mode switch
H1 Warning beacon	S18 Screed temperature switch
H2 Auger lighting	Y1 Conveyor/auger right
I1 Burner ignition (left)	Y2 Conveyor/auger reverse
I2 Burner ignition (middle)	Y3 Screed extension left ejection
I3 Burner ignition (right)	Y4 Screed extension left retraction
K1 - K6 Relay	Y5 Screed extension right retraction
K10 Relay	Y6 Screed extension right ejection
M1 Oil cooling fan	Y7 Brake release
P1 Horn	Y8 Screed floating position
P2 Reverse beeper	Y9 Screed release
R1 Speed control POT wiper	Y10 Screed lift
R2 Pump angle POT wiper	Y11 Screed vibration
R3 - R6 Resistor	Y12 Drive pump forward
S1 Disconnecter	Y13 Drive pump back ward
S2 Emergency brake button	Y14 Solenoid of the gas shut-off valve
S3 Ignition switch	Y15 Solenoid of the gas shut-off valve
S5 Oil temperature switch	



Machine hydraulic system diagram

Legend:

- 1 Travel pump
- 2 Operating pump
- 3 Left travel motor
- 4 Right travel motor
- 5 Suction return filter
- 6 Hydraulic oil cooler
- 7 Hydraulic system block
- 8 Augers
- 9 Screed lifting/lowering hydraulic cylinder
- 10 Left paving width hydraulic cylinder
- 11 Right paving width hydraulic cylinder
- 12 Control unit
- 13 Steering
- A.1 *Vibration unit right
- A.2 *Vibration unit left



Measuring points of the hydraulic circuit


The table shows the list of the hydraulic circuit measuring points located on the machine.

Note

See the procedure for measuring the pressure in the hydraulic circuit in the workshop manual delivered upon a special order.

	Mode	Pressure (bar)
Measuring point no. 1	Conveyor (maximum speed)	155±5
	Auger (maximum speed)	100±4
	Screed lifting (maximum speed)	55±5
	Screed extension (maximum speed)	55±5
	Vibrations + travel (maximum speed)	55±5
	Steering (maximum speed)	55±5
Measuring point no. 2	Forward travel	172±10
Measuring point no. 3	Refilling pressure (maximum speed)	20±2
	Refilling pressure (idle speed)	22+4/-2
Measuring point no. 4	Reverse travel	172±10





Screed gas heating system diagram

Legend:

- 1 Automatic screed heating ignition boxes
- 2 Gas supply solenoid valves
- 3 Spark plugs
- 4 Cables
- 5 Cable
- 6 Gas supply manifold
- 7 Gas hose
- 8 Gas hose
- 9 Gas hose
- 10 Reducing valve
- 11 Screed heating fuse, 5 A
- 12 Safety valve

