




IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



**Stocked
at Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
	Electric Log Assembly	No longer available	4030-055	
1	120VAC Heater Assembly	No longer available	SRV4030-541	
		No longer available	4050-104	
2	Upper Glass Retainer	No longer available	4030-146	
3	Lenticular Lens	No longer available	4030-808	
4	Acrylic Panel	No longer available	4030-899	
5	Grate	No longer available	4030-896	
6	Ember Bed	No longer available	4030-914	
7	Rock Retainer	No longer available	4030-157	
8	Screen & Rod Assembly	No longer available	4030-033	
9	Upper Grille Assembly	No longer available	4030-088	
10	Hood	No longer available	4030-531	
11	Lower Grille Assembly	No longer available	4030-087	
12	Light Tray Assembly	No longer available	SRV-020	
13	Flame Element Kit	No longer available	4030-200	
14	Halogen Light	Qty. 2 req.	33961	Y
15	Motor w/Vinyl Cover Assembly	No longer available	4030-883	
	Power Cord	No longer available	4030-018	
	Reflective Flame Decal	No longer available	4021-190	