




CFM RMC International reserves the right to make changes in design, materials, specifications, prices and discontinue colors and products at any time, without notice.

RMC-LC NGT/LPT Unvented Room Heater

Item/Model Number	RMC-LC10NGT/LPT	RMC-LC20NGT/LPT	RMC-LC30NGT/LPT
1. Guard Assembly	RBW33XX0	RBW30XX0	RBW26XX0
2. Glass Panel	RBC02XC0	RBC02XB0	RBC02XA0
3. Glass Holder	RBP63PC0	RBP63PB0	RBP63XPA0
4. Reflector	RBP71XX0	RBP70XX0	RBP62XB0
5. Front Panel	RBP69XX0	RBP66XA0	RBP57XX0
6. Leg - Front	RBI06XX0	RBI06XX0	RBI06XX0
7. Heat Cover - Upper	RCP38	RCP37	RCP36
8. Burner Assembly	RBW13XX0	RBW09XX0	RBW08XX0
9a. Burner Support - Left	RBP60XA0	RBP60XA0	RBP60XA0
9b. Burner Support - Right	RBP60XB0	RBP60XB0	RBP60XB0
10. Body Frame Assembly	RBW32XC0	RBW28XC0	RBW21XC0
11. Leg - Rear	RBI05XX0	RBI05XX0	RBI05XX0
12. Valve Bracket	RBP73XA0	RBP73XA0	RBP73XA0
13a. Combination Gas Control - Natural	3RH0002C	3RH0002D	3RH0002F
13b. Combination Gas Control - LP	3RH0002B	3RH0002C	3RH0002E
14. ODS Tubing Assembly	RCT75	RCT77	RCT79
15. Outlet Tubing Assembly	BBT44	BBT46	BBT48

RMC-LC NGT/LPT (continued)

iBuyFireplaceParts.com


888-634-4289

Item/Model Number	RMC-LC10NGT/LPT	RMC-LC20NGT/LPT	RMC-LC30NGT/LPT
16. Inlet Tubing Assembly	RBT42	RBT45	RBT47
17. Nozzle Holder	RBM06XX0	RBM06XX0	RBM06XX0
18. Fix Nut - Nozzle Holder	RBM08XX0	RBM08XA0	RBM08XX0
19a. Main Nozzle - Natural	RBM07XEO	RBM07XA0	RBM07XC0
19b. Main Nozzle - LP	RBM07XF0	RBM07XB0	RBM07XD0
20a. ODS Pilot Assembly - Natural	DS98JN01	DS98JN01	DS98JN01
20b. ODS Pilot Assembly - LP	DS98JL01	DS98JL01	DS98JL01
21. Shield	RBP84	1RH0001A	RBP83
22. Rear Radiant Shield	-	3RH0003A	-
23a. Pressure Regulator - Natural	DR40T2PN	DR40T2KN	DR40T3KN
23b. Pressure Regulator - LP	DR40T2PL	DR40T2KL	DR40T3KL

iBuyFireplaceParts.com

iBuyFireplaceParts.com

888-634-4289



CFM RMC International reserves the right to make changes in design, materials, specifications, prices and discontinue colors and products at any time, without notice.

RMC-LI NGT/LPT Unvented Room Heater

Item/Model Number	RMC-LI10NGT/LPT	RMC-LI18NGT/LPT	RMC-LI30NGT/LPT
1. Lower Heat Cover	RCP10XE0	RCP10XD0	RCP10XC0
2. Guard Assembly	RBW33XE0	RBW30XX0	RBW26XX0
3. Reflector	RCP34XX0	RCP33XX0	RCP28XX0
4. Upper Heat Cover	RCP38	RCP37	RCP36
5. Leg - Front	RBI06XX0	RBI06XX0	RBI06XX0
6. Front Panel	RBP69XX0	RBP66XA0	RBP57XX0
7. Burner Assembly Body	5RH0003	5RH0004	5RH0005
8. Ceramic - Plate	3A0040B	3A0040A	3A0040A
9. Body Frame Assembly	RBW32XC0	RBW28XC0	RBW21XC0
10. Leg - Rear	RBI05XX0	RBI05XX0	RBI05XX0
11. Bracket - Valve	RBP73XA0	RBP73XA0	RBP73XA0
12. Combination Gas Control	3RH0002A	3RH0002A	3RH0002A
13. ODS Tubing Assembly	RCT75	RCT77	RCT79
14. Outlet Tubing Assembly	RCT74	RCT76	RCT78
15. Inlet Tubing Assembly	RBT42	RBT45	RBT47
16a. ODS Pilot Assembly - Natural	DS98JN01	DS98JN01	DS98JN01
16b. ODS Pilot Assembly - LP	DS99JL01	DS98JL01	DS98JL01