





## Cylinder Head Subassembly



Id	Item #	Description	Quantity	Rev	Comments
5	45-0783	GASKET, CYLINDER HEAD	1		
6	45-0559	COVER SUBASSEMBLY, CYLINDER HEAD	1		
7	45-0560	GASKET, CYLINDER HEAD COVER	1		
8	45-0784	TUBE, BREATHER	1		
9	45-0562	BOLT SUBASSEMBLY, CYLINDER HEAD COVER	1		
10	45-0563	CYLINDER EPICRANIUM BOLT SEAL & GASKET UNIT (INC. 11)	1		
12	45-0382	STUD	2		
13	45-0323	STUD	2		
14	45-0330	PIN	2		
15	45-0239	BOLT, CYLINDER HEAD	4		
16	45-0471	PLUG, SPARK	1		
17	45-0785	HEAD SUBASSEMBLY, CYLINDER	1		



## Crankcase//governor gear Assembly




Id	Item #	Description	Quantity	Rev	Comments
1	45-0786	CRANKCASE SUBASSEMBLY.	1		
2	45-0333	SEAL, OIL	1		
3	45-0787	SENSOR, ENGINE OIL	1		
4	45-0286	FRAME? FUEL TANK INSTALLTION	1		
5	45-0306	PLUG, RUBBER	1		
6	45-0313	PROTECTOR, OIL	1		
7	45-0315	BOLT	1		
8	45-0326	WASHER	2		
9	45-0236	BOLT, DRAIN PLUG	2		
10	45-0335	CLIP	1		
11	45-0360	ARM, GOVERNOR	1		
12	45-0327	WASHER	1		
13	45-0328	PIN	1		
14	45-0320	BOLT	2		
15	45-0788	BOLT	2		

<b>Id</b>	<b>Item #</b>	<b>Description</b>	<b>Quantity</b>	<b>Rev</b>	<b>Comments</b>
16	45-0789	NUT	1		
17	45-0316	BOLT	2		




## Crankcase Cover Subassembly



Id	Item #	Description	Quantity	Rev	Comments
1	45-0817	COVER , CRANKCASE	1		
2	45-0340	GASKET, CRANKCASE	1		
3	45-0273	PLUG SUBASSEMBLY, ENGINE OIL	1		
4	45-0272	DIPSTICK SUBASSEMBLY, OIL	1		
6	45-0329	PIN	2		
7	45-0389	BOLT	7		
8	45-0818	BEARING	1		
9	45-0365	GEAR ASSY, GOVERNOR	1		
18	45-0333	SEAL, OIL	1		




## Crankshaft Assembly



Id	Item #	Description	Quantity	Rev	Comments
1	45-0790	CRANKSHAFT ASSY	1		




## Piston Subassembly



Id	Item #	Description	Quantity	Rev	Comments
1	45-0791	RING, PISTON	1		
2	45-0792	PIN, PISTON	1		
3	45-0793	CLIP, PISTON PIN	1		
4	45-0794	PISTON	2		
5	45-0795	ROD, CONNECTING	1		
7	45-0796	RING, THE FIRST	1		
8	45-0797	RING, THE SECON	1		
9	45-0798	RING SET, OIL	1		




## Valve Train//Camshaft Subassembly



Id	Item #	Description	Quantity	Rev	Comments
1	45-0799	CAMSHAFT ASSY.	1		
3, 4	45-0800	VALVE	1		
3	45-0801	VALVE, EXHAUST	1		
4	45-0802	VALVE, INTAKE	1		
5	45-0803	SEAT, VALVE SPRING	2		
6	45-0804	CLAMP, VALVE LOCK	4		
7	45-0805	SPRING, VALVE	2		
8	45-0806	GUIDE, SEAL	2		
9	45-0265	TAPPET, VALVE	2		
10	45-0807	LIFTER, VALVE	2		
11	45-0266	PLATE SUBASSEMBLY, LIFTER STOPPER	1		
12	45-0270	BOLT, VALVE ADJUSTING	2		
13	45-0268	ROCKER, VALVE	2		
14	45-0271	NUT? VALVE ADJUSTING	2		
15	45-0269	NUT, VALVE LOCK	2		
16	45-0245	RETAINER, VALVE SPRING	1		




## Recoil Starter



Id	Item #	Description	Quantity	Rev	Comments
1	45-0808	STARTER ASSY, RECOIL	1		
2	45-0381	BOLT	3		




## Shrouds



Id	Item #	Description	Quantity	Rev	Comments
1	45-0378	SHROUD	1		
2	45-0375	SHROUD, CYLINDER BODY	1		
3	45-0315	BOLT	1		
4	45-0809	SWITCH SUBASSEMBLY, STOP ENGINE	1		
5	45-0315	BOLT	5		
8	45-0336	CLIP	1		




## Carburetor Assembly



Id	Item #	Description	Quantity	Rev	Comments
1	45-0810	CARBURETOR ASSY.	1		
2	45-0295	GASKET, AIR CLEANER	1		
3	45-0358	GASKET, CARBURETOR	1		
33	45-0811	PLATE, CARBURETOR INSULATOR	1		
34	45-0368	GASKET, CARBURETOR INSULATOR	1		




### Air Cleaner (Before sn A2203001964)



Id	Item #	Description	Quantity	Rev	Comments
10-01	2	HEXAGON NUT WITH FLANGE	80-0469		
10-02	1	AIR CLEANER	45-0812		
10-04	1	BOLT	45-0915		
10-05	1	AIR FILTER ELEMENT	45-0387		




## Air Cleaner (After sn A2203001964)



Id	Item #	Description	Quantity	Rev	Comments
11-03	2	HEXAGON NUT WITH FLANGE	80-0469		
11-06	1	AIR FILTER - 300CC	45-0906		
11-09	1	AIR FILTER COVER - 300CC	45-0907		
11-10	2	BUTTERFLY NUT - STAMPED	45-0905		
11-12	1	BOLT	45-0896		
11-13	1	AIR FILTER ASSEMBLY - 300CC	45-0908		
11-14	1	SEALING WASHER - 1/4" NEOPRENE	28-1072		




## Muffler Assembly



Id	Item #	Description	Quantity	Rev	Comments
4	45-0371	BLOCK, MUFFLER SEAT REINFORCING	1		
5	45-0813	PIPE, EXHAUST	1		
6	45-0301	GASKET, EXHAUST OUTLET	1		
7	45-0436	NUT	3		
8	45-0436	NUT	2		
9	45-0814	MUFFLER ASSY.	1		




## Fuel Tank Assembly



Id	Item #	Description	Quantity	Rev	Comments
1	45-0413	TANK, FUEL	1		
2	45-0411	STRAINER?FUEL	1		
3	45-0412	COVER, FUEL TANK	1		
4	45-0289	OUTLET SUBASSEMBLY, FUEL TANK OIL	1		
5	45-0338	CARB CANISTER HOSE COLLAR	2		
6	45-0386	TUBE, FUEL	1		
8	45-0436	NUT	2		
9	45-0336	CLIP	2		




## Flywheel//Impeller/Starter Pulley/Ignition Coil



Id	Item #	Description	Quantity	Rev	Comments
1	45-0262	NUT, FLYWHEEL	1		
2	45-0377	PULLEY, STARTER	1		
3	45-0376	IMPELLER	1		
4	45-0815	FLYWHEEL SUBASSEMBLY	1		
6	45-0318	BOLT	2		
8	45-0816	COIL, IGNITION	1		



## Throttle Control Assembly



Id	Item #	Description	Quantity	Rev	Comments
1	45-0366	CONTROL SUBASSEMBLY, THROTTLE	1		
2	45-0277	SPRING, THROTTLE VALVE RETURNING	1		
3	45-0361	ROD, GOVERNOR	1		
4	45-0362	SPRING, GOVERNOR	1		
5	45-0363	SUPPORT SUBASSEMBLY, GOVERNOR	1		
6	45-0315	BOLT	2		
13	45-0324	NUT	1		
14	45-0282	BOLT, GOVERNOR SUPPORT	1		