


EXPLODED PARTS



PARTS LIST

P-080 Hammer
P-084 White rubber cap
P-154 Handle grip
Q-001 Head cap
Q-006 Head body
Q-006A o-ring
Q-016 Main body
Q-016A o-ring
Q-018 Main cylinder
Q-018A Band-valve
Q-022 Piston
Q-022A Wear ring

Q-022B o-ring
Q-023 Driving blade
Q-025A Bumper
Q-025B Seal bushing
Q-029 Foot
Q-032 Gate
Q-033 Adjustable base
Q-034 Resting block
Q-034A Bracket
Q-035 A&B Brackets
Q-036 Cam axle
Q-036A&B Cam

Q-042 Actuator
Q-042A u-cup seal
Q-043 Valve
Q-044 Actuator cap
Q-046 Clip assembly
Q-048 Feeder channel
Q-061 Safety anchor
Q-061B Connecting stem
Q-061D Spring
Q-062 Safety contact
Q-062A Locking rod

QEPParts.com
888-634-4289
An iBuy Stores Company