




iBuyGrillParts.com
888-634-4289

Ref#	Part#	Description	Qty Req'd
2	50001844B	GREASE PAN SUPPORT	2
3	50003320	DOOR ASSEMBLY	1
4	50003322B	DOOR FASCIA	1
5	50003208	DOOR HANDLE ROUND	1
6	50000313	DOOR HANDLE	1
7	50001842	GREASE PAN	1
8	50000879	FLASH TUBE	1
9	50000892	BURNER GASKET	4
10	50003133K	BURNER ASSEMBLY - INCLUDES ELECTRODE AND WIRE	4
12	50000431	ELECTRODE MAIN SHORT	2
13	91D0108	ELECTRODE WIRE MAIN LONG - NEED 91D0107 FOR ELECTRODE	2
13a	91D0107	ELECTRODE ONLY - MAIN	2
14A	50003583	VALVE, MANIFOLD ASSEMBLY (LP)	1
14B	50003584	VALVE, MANIFOLD ASSEMBLY (NG)	1
15A	50003815	HOSE REGULATOR ASSEMBLY - 2 SIDED LP	1
15B	50002901	S. BURNER VALVE ASSEMBLY (NG)	1
16	50000777	HEAT PLATE - SS	4
17	50000156	COOK GRATE - SINGLE APPROX 16 X 9	3
18	50001416	ROTISSERIE HOUSING & SCREEN ASSEMBLY	1
19	50000047	ROTISSERIE BURNER ASSEMBLY	1
20A	50001415	ROTISSERIE GAS TUBE (LP)	1
20B	50001428	TUBE & ORIFICE ASSEMBLY (NG)	1
21	50003129	ROTISSERIE ELECTRODE	1
22	50003881	CONSOLE	1
23	50003319B	CONSOLE REINFORCEMENT	1
24	50002788	IGNITOR PUSH BUTTON	1
25	50002533	IGNITOR PLATE	1
26	50001619	IGNITOR MODULE- PUSHBUTTON NOT INCL. (ON OLDER VC GRILLS SOME MODIFICATION MAY BE REQUIRED TO MOUNT)	1
28	50003002	BEZEL ASSEMBLY (BACKLIT)	5
29	50003003	KNOB ASSEMBLY (BACKLIT)	5
30	30006788K	REAR LID ASSEMBLY (REQUIRES PART 50000355)	1
31	50003069	LID ASSEMBLY FRONT (REQUIRES PART 50000355)	1
32	50001643	TEMPERATURE GAUGE - SUBS to 20300395 & 20300394	1
33	50000642	GRIP HANDLE SET	1
34	50000365	LID BUMPERS (SET OF 6)	1
35	50000355	PIVOT PIN & BOLT SET - SEND WITH LID ASSEMBLY	1
36	30005576	WARMING RACK (ENAMEL)	1
37	50003043M	SIDE BURNER ASSEMBLY	1
38	50003106	SIDE SHELF LIGHT ASSEMBLY (PERISCOPE)	1
39	50003116	ROTISSERIE KIT (SPIT ROD NOT INCLUDED)	1
40	50000161	ROTISSERIE MOTOR	1
41	50000286	ROTISSERIE SPIT ROD	1
42	50000115	ELECTRODE - SIDE BURNER	1
43	50001044	BURNER (FOR THE SIDE BURNER)	1
44	50000113	CONTROL KNOB - SIDE BURNER	1
45	50001046	SIDE BURNER VALVE (LG)	1
46	50000070	IGNITOR KNOB - SIDE BURNER	1
47	50000111	ROTARY IGNITOR - SIDE BURNER	1
48	50001035	SIDE BURNER GRATE	1
49	50003304B	CONDIMENT TRAY - LEFT	1
50	50003282B	CONDIMENT TRAY - RIGHT	1
51	50003333	LEFT SIDE SHELF	1
52	50003330	RIGHT SHELF (SIDE BURNER)	1
53	50003314	FRONT TABLE SUPPORT - RIGHT	1
54	50003315	FRONT TABLE SUPPORT - LEFT	1
55	50001418	SHELF SUPPORT BLACK	1
56	50001419	SHELF SUPPORT BLACK	1
57	50003059	SIDE BURNER LID ASSEMBLY	1
58	50003011	UTENSIL HOOK (PACK OF 3)	1
59	50001845	GREASE CUP	1
60	50003068	CASTER 3 X 7/8	4
61	50002888	CYLINDER RETAINER (LP MODELS ONLY)	1
62	50003198	STABILIZER BRACKET ASSEMBLY	1
63	VCDC45B	DELUXE BBQ COVER - CAN SUB VCS08C4	1
N/S	50002198	CABINET FORM BLOCK - THERMOPLASTIC	4

iBuyGrillParts.com
888-634-4289