



Spare Parts Information

KEY



USE
LOCTITE



USE
OIL



USE
SILICONE

For information regarding Spare Parts availability for this machine, please visit www.Belle247.com or contact the ALTRAD Belle using the following contact details:-

Tel:- +44 (0)1298 84606

Fax:- +44 (0)1298 84722

Email:- sales@ALTRAD-Belle.com

- Colour Option 1

Part No. + S = Orange (Eg. 981/05100S)

Part No. + G = Green

Part No. + B1 = Blue

Part No. + R1 = Red

Part No. + Y = Yellow

Part No. + Y2 = Yellow

- Colour Option 2

Part No. + GR = Grey (Eg. 981/03200GR)

Part No. + GR2 = Quartz Grey

Part No. + BL = Black

Part No. + W = White

Spare Parts Information



KEY



USE
LOCTITE



USE
OIL



USE
SILICONE

For information regarding Spare Parts availability please contact the ALTRAD Belle Inc. using the following contact details:-

Altrad Belle Inc, PO Box 13225, Roanoke, VA, 24032, USA
Tel : +1 540.345.5090, Fax: +1 540.345.5091


Email : sales@bellegroup.net

- Colour Option 1

Part No. + S = Orange (Eg. 981/05100**S**)
Part No. + G = Green
Part No. + B1 = Blue
Part No. + R1 = Red
Part No. + Y = Yellow
Part No. + Y2 = Yellow

- Colour Option 2

Part No. + GR = Grey (Eg. 981/03200**GR**)
Part No. + GR2 = Quartz Grey
Part No. + BL = Black
Part No. + W = White



Chassis & Vibrator Assembly



1-01

1 - ##	981/06000.....	Chassis	Chassis	Chassis	Chassis	1
2	981/99984.....	Shaft.....	Axe	Eje	Veio	1
3	981/99979.....	Cover	Couvercle.....	Cubierta	Tampa	1
4	981/99985.....	Spacer	Entretoise.....	Espaciador	Espaçador	1
5	7/8037.....	Screw.....	Vis	Tornillo	Parafuse	M8 x 2012
6	8/8007.....	Nut	Ecrou	Tuerca	Porca	M86
7	7/16006.....	Screw.....	Vis	Tornillo	Parafuse	M165
8	53/0089.....	Bearing.....	Roulement	Cojinete	Rolamento	2
9	981/99906.....	Pulley.....	Poulie	Polia	Polia	1
10	981/99907.....	Washer.....	Rondelle	Arandela	Anilha	1
11	8/12006.....	Nut	Ecrou	Tuerca	Porca	M1216
12	4/1204.....	Washer.....	Rondelle	Arandela	Anilha	M1220
13	9/12019.....	Bolt.....	Boulon.....	Perno	Perno	M12 x 558
14	02.5.019.....	Screw.....	Vis	Tornillo	Parafuse	4
15	4/1005.....	Washer.....	Rondelle	Arandela	Anilha	M1012
16	4/1003.....	Washer.....	Rondelle	Arandela	Anilha	M104
17	7/10010.....	Screw.....	Vis	Tornillo	Parafuse	M10 x 308
18	21/0335.....	Anti-Vibration Mount	Tampon antivibratoire	Montura antivibratoria	Bloco Anti-vibração	4
19	981/99957.....	Scraper	Racleur	Arrastre	Raspadeira	2
20	7/12013.....	Screw.....	Vis	Tornillo	Parafuse	M12 x 3524
21	4/1202.....	Washer.....	Rondelle	Arandela	Anilha	M1224
22	981/06400.....	Pipe	Tubo	Pistão	Zuiger	4
23	3/3015.....	Grommet.....	Passe-fil	Ojal.....	Anel Isolante.....	Ø25mm2
24	981/04600.....	Scraper	Racleur	Arrastre	Raspadeira	2

AltradParts.com

888-634-4289

An iBuy Stores Company



Bedplate Assembly

2-01

1	9-01	Hydraulic Pump	Pompe hydraul.	Bomba hidráulica	Bomba hidráulica	1
2	9-01	Layshaft Assembly	Assemblée arbre intermédiaire	Asamblea eje intermedio	Montagem do Eixo Intermediário	1
3-##	981/02900	Bracket	Patte de montage	Escuadra	Suporte	1
4-##	981/06100	Bedplate	Plaque d'Assise	Placa de Apoio	Placa de Apoio	1
5-##	981/06200	Frame	Châssis	Estructura	Estructura	1
6	981/03700	Plate	Plaque	Placa	Placa	1
7	981/99923	Hook	Crochet	Gancho	Gancho	1
8	981/99939	Plate	Plaque	Placa	Placa	1
9-##	981/04800	Clamp	Bride	Moradaza	Grampo	1
10	981/99980	Bracket	Patte de montage	Escuadra	Suporte	1
11	981/99987	Plate	Plaque	Placa	Placa	1
12	981/99986	Screw	Vis	Tornillo	Parafuse	1
13	70/0270	Battery	Batterie	Bateria	Bateria	1
14	3/3014	Grommet	Passerell.	Ojal	Anel Isolante	055mm
15-##	981/07200	Railing	Garde-Fou	Barandilla	Grade	1
16-##	981/99983	Cover	Couvercle	Cubierta	Tampa	Yanmar
17	7/10039	Screw	Vis	Tornillo	Parafuse	M10 x 20
18	161/99750	Pin	Goupille	Pasador	Pino	1
19	161/99747	Pulley	Poulie	Polia	Polia	1
20	53/0016	Bearing	Roulement	Coinete	Rolamento	1
21	3/9003	Circlip	Circlip	Resorte circular	Grampo circular	1
22	MS22	Circlip	Circlip	Resorte circular	Grampo circular	1
23	8/8008	Nut	Ecrou	Tuerca	Porca	M8
24	4/8001	Washer	Rondelle	Arandela	Anilha	M8
25	8/8003	Nut	Ecrou	Tuerca	Porca	M8
26	4/8003	Washer	Rondelle	Arandela	Anilha	M8
27	7/12003	Screw	Vis	Tornillo	Parafuse	M12
28	4/1202	Washer	Rondelle	Arandela	Anilha	M12
29	4/1204	Washer	Rondelle	Arandela	Anilha	M12
30	4/1201	Washer	Rondelle	Arandela	Anilha	M12
31	4/8006	Washer	Rondelle	Arandela	Anilha	M8
32	7/8037	Screw	Vis	Tornillo	Parafuse	M8
33	9/10001	Bolt	Boulon	Perno	Perno	M10
34	4/1003	Washer	Rondelle	Arandela	Anilha	M10
35	4/1005	Washer	Rondelle	Arandela	Anilha	M10
36	9/10030	Bolt	Boulon	Perno	Perno	M10
37	7/8012	Screw	Vis	Tornillo	Parafuse	M8
38	7/6034	Screw	Vis	Tornillo	Parafuse	M6
39	8/6011	Nut	Ecrou	Tuerca	Porca	M6
40	2/0061	Spring	Ressort	Resorte	Mola	1
41	981/99961	Plunger	Plongeur	Embolo	Embolo	M16
42	7/16014	Washer	Rondelle	Arandela	Anilha	M8
43	74/0028	Knob	Poignée	Pomo	Botão	1
44	20071	Washer	Rondelle	Arandela	Anilha	M10
45	3/4112	Sung	Banderolage hélicoïdal	Abriço Espiral	Indicador em Espiral	1
46	3/4047	Washer	Rondelle	Arandela	Anilha	M10
47	7/12013	Screw	Vis	Tornillo	Parafuse	M12
48	70/0267	Buzzer	Vibreur	Zumbador	Sirene	1
49	7/5024	Screw	Vis	Tornillo	Parafuse	M5
50	4/5002	Washer	Rondelle	Arandela	Anilha	M6 x 30
51	8/5003	Nut	Ecrou	Tuerca	Porca	M5
52	981/99805	Wedge	Coinçage	Calzo	Calço	1
53	981/07900	Driveline Kit	Kit de Transmission	Kit de Accionamiento	Conjunto do Transmissão	1
54	21/0283	Butler	Butor	Parachoques	Amortecedor	2


* - If ordering item 15 please order 2 x item 52 also.

- To see the colour options for this part, please see the '# ' area of the 'Spare Parts Information' section of the Operators Manual.

- To see the colour options for this part, please see the '## ' area of the 'Spare Parts Information' section of the Operators Manual.

Yanmar

2-02



Kubota

Side Guards


2-02

1 - #	981/99982	Side Guard	Couvercle latéral	Tapa lateral	Tampa lateral	Yanmar	1
1 - #	981/99981	Side Guard	Couvercle latéral	Tapa lateral	Tampa lateral	Kubota	1
2 - #	981/06700	Side Guard	Couvercle latéral	Tapa lateral	Tampa lateral	Yanmar	1
3 - #	981/07000	Side Guard	Couvercle latéral	Tapa lateral	Tampa lateral	Kubota	1
4	7/8037	Screw	Vis	Tornillo	Parafuse		11
5	981/998002	Plate	Plaque	Placa	Placa		1
6	981/99803	Plate	Plaque	Placa	Placa		1
7	7/6046	Screw	Vis	Tornillo	Parafuse		10
8	4/6001	Washer	Rondelle	Arandela	Anilha		10
9	8/6007	Nut	Ecrou	Tuerca	Porca		10

AltradParts.com

888-634-4289

An iBuy Stores Company




Controls

1	981/99920	Buffer	Butoir	Parachouques	Amortecedor	1
2	919/99826	Spring	Ressort	Resorte	Mola	1
3	981/99912	Bar	Barre	Barra	Barra	1
4 - ##	981/03200	Handle	Guidon	Manillar	Punho	1
5	981/05500	Self-Centre Assembly				1
6 - #		Cover	Couvercle	Cubierta	Tampa	1
7	981/99965	Plate	Plaque	Placa	Placa	2
8	74/0026	Knob	Poignée	Pomo	Botão	2
9	981/03212	Washer	Rondelle	Arandela	Anilha	4
10	981/03211	Spacer	Entretoise	Espaciador	Espaçador	1
11	981/03300	Lever	Levier	Palanca	Alavanca	1
12	981/99958	Bar	Barre	Barra	Barra	1
13	981/03400	Lever	Levier	Palanca	Alavanca	1
14 - #		Cover	Couvercle	Cubierta	Tampa	1
15	500/06100	Grease Nipple	Téton de graissage	Conexión para engrase	Bocal de Lubrificação	2
16	8/6007	Washer	Rondelle	Arandela	Anilha	M6
17	981/99931	Pin	Goupille	Pasador	Pino	1
18	2/0071	Spring	Ressort	Resorte	Mola	1
19	8/8008	Nut	Ecrou	Tuerca	Porca	M8
20	4/8004	Washer	Rondelle	Arandela	Anilha	M8
21	981/99932	Boss	Bossage	Resalte	Cubo	1
22	981/99915	Vibrator Cable	Câble de vibrateur	Cable del vibrador	Cabo Vibratória	1
23	981/99917	Control Cable	Câble de commande	Cable de control	Cabo de Controlo	1
24	981/99966	Spacer	Entretoise	Espaciador	Espaçador	1
25	981/03900	Clevis	Chape	Horquilla	Grampo	1
26	3/0039	Pin	Goupille	Pasador	Pino	1

Altradrarts.com

888-634-4289

An iBuy Stores Company




Drum Assembly

1	2/0046	Spring	Ressort	Resorte	Mola	1
2	7/6008	Screw	Vis	Tornillo	Parafuse	M6 x 8 1
3	919/99843 1	Boss	Bossage	Resalte	Cubo	1
4	919/99843 2	Bar	Barre	Barra	Barra	1
5	74/0001	Knob	Poignée	Pomo	Botão	1
6	981/00301	Support	Support	Soporte	Suporte	1
7	3/9013	Circlip	Circlip	Resorte circular	Grampo circular	1
8	53/0085	Bearing	Roulement	Cojinete	Rolamanto	1
9	981/00100	Drum	Tambour	Tamburo	Tambor	1
10	4/3902	Washer	Rondelle	Arandela	Anilha	M3 1
11	981/99997	Hub	Moyeu	Cubo Reductor	Cubo da Roda	1
12	4/1204	Washer	Rondelle	Arandela	Anilha	M12 4
13	981/07400	Wheel Motor Bolt Kit	Kit de boulon de	Kit Perno motor de la rueda	Kit de parafuso motor de roda	4
14	981/07400	Wheel Motor Bolt Kit	Kit de boulon de	Kit Perno motor de la rueda	Kit de parafuso motor de roda	4
15	981/07800	Kit	Kit	Kit	Kit	4
15	981/00105	Support	Support	Soporte	Suporte	1
16	53/0084	Bearing	Roulement	Cojinete	Rolamanto	2
17	3/9030	Circlip	Circlip	Resorte circular	Grampo circular	Ø80 1
18	6/1148	Hydraulic Motor	Moteur Hydraulique	Motor hidráulico	Motor hidráulico	1
19	981/00501	Support	Support	Soporte	Suporte	1
20	8/2004	Nut	Ecrou	Tuerca	Porca	1
21	21/0351	Key	Clavette	Chaveta	Chave	1
22	981/07400	Kit	Kit	Kit	Kit	4
22	7/12042	Screw	Vis	Tornillo	Parafuse	Ø440 8
23	981/07400	Kit	Kit	Kit	Kit	1
23	4/1218	Washer	Rondelle	Arandela	Anilha	Ø440 8
24	981/99806	Shim	Cale	Cuña	Calço	A/R
25	9/12042	Screw	Vis	Tornillo	Parafuse	Ø440 4
26	4/1218	Washer	Rondelle	Arandela	Anilha	Ø440 4
27	8/12013	Nut	Ecrou	Tuerca	Porca	Ø440 4

Not Shown

-	5/0088	Seal Kit	Jeu étanchéité	Juego retenes	Conjinto de Vedação	1
-		Hydraulic Motor	Moteur Hydraulique	Motor hidráulico	Motor hidráulico	1




Yanmar L100N Engine Assembly

5-01

1	20/0111.....	Engine.....	Moteur	Motor	Motor	Yanmar L100N	1
2	21/0281.....	Belt.....	Courroie	Correa	Cinta		2
3	21/0111.....	Belt.....	Courroie	Correa	Cinta		3
4	21/0341.....	Clutch.....	Embrayage	Embrague	Embraiagem		1
5	981/99946.....	Spacer	Entretoise	Espaciador	Espaçador		1
6	7/10057.....	Screw.....	Vis	Tornillo	Parafuse		1
7	21/0377.....	Key.....	Clavette	Chaveta	Chave		1
8	9/10030.....	Bolt.....	Boulon	Perno	Perno		4
9	4/1003.....	Washer	Rondelle	Arandela	Anilha	M10	4
10	4/1005.....	Washer	Rondelle	Arandela	Anilha	M10	4
11	6/0243.....	Adaptor	Adaptateur	Adaptador	Adaptador		1
12	5/0038.....	Seal	Joint d'étanchéité	Obturator	Vedação		1
13	32/0142.....	Hose	Tuyau	Manguera	Tubagem		1
14	6/2023.....	Adaptor	Adaptateur	Adaptador	Adaptador		1
15	6/2024.....	Cap	Capuchon	Casquete	Tampa		1
16	71/0271.....	Harness	Faisceau	Arnés	Cablagem		1
17	21/0349.....	Filter	Filtre	Filtro	Filtro		1
18	3/7043.....	Clip.....	Collier	Presilla	Grampo		2
19	21/0369.....	Pipe	Tubo	Pistão	Zuiger		1
20	21/0053.....	Air Filter	Filtre à air	Filtro de aire	Filtro de Ar		1
21	21/0052.....	Bracket	Patte de montage	Escuadra	Suporte		1
22	21/0391.....	Filter Element.....	Élément Filtre	Elemento Filtro	Elemento Filtrante		1
23	21/0405.....	Dipstick	Jauge	Varilla para medición	Vareta de Medição		1
			del nivel del aceite	de Nivel			1
24	21/0408.....	Boss	Bossage	Resalte	Cubo		1
25	5/0095.....	O Ring.....	Joint torique	Junta tórica	Anel Vedante		1
26	21/0407.....	Boss	Bossage	Resalte	Cubo		1
27	981/99902.....	Support	Support	Soporte	Soporte		1
28	3/9032.....	Circlip.....	Circlip	Resorte circular	Grampo circular		1
29	34/0049.....	Hose	Tuyau	Manguera	Tubagem		1
30	3/7018.....	Clip.....	Collier	Presilla	Grampo		2

Altradarts.com
888-644-4289


An iBuy Stores Company



Kubota EA330 Engine Assembly

1	20/0120.....	Engine.....	Moteur	Motor	Motor	Kubota EA330.....	1
2	71/0275.....	Harness	Faisceau	Arnés	Cablagem		1
3	21/0378.....	Belt.....	Courroie	Correa	Cinta		2
4	21/0111.....	Belt.....	Courroie	Correa	Cinta		3
5	981/99933.....	Spacer	Entretoise	Espaciador	Espaçador		1
6	21/0341.....	Clutch.....	Embrayage	Embrague	Embraiagem		1
7	21/0372.....	Key.....	Clavette	Chaveta	Chave		1
8	7/10010.....	Screw.....	Vis	Tornillo	Parafuse		4
9	4/1003.....	Washer	Rondelle	Arandela	Anilha	M10	4
10	981/99988.....	Washer	Rondelle	Arandela	Anilha		1
11	4/1005.....	Washer	Rondelle	Arandela	Anilha	M10	3
12	9/8019.....	Bolt.....	Boulon	Perno	Perno		4
13	4/8003.....	Washer	Rondelle	Arandela	Anilha	M8	4
14	4/8006.....	Washer	Rondelle	Arandela	Anilha	M8	4

AltradParts.com
888-634-4289
An iBuy Stores Company



Handle Assembly


1 - ##	981/06500	Handle	Guidon	Manillar	Punho	1
2 - ##	981/99992	Plate	Plaque	Placa	Placa	1
3	161/99543	Bearing	Roulement	Cojinete	Rolamento	2
4	8/16005	Nut	Ecrou	Tuerca	Porca	2
5	05.1.009	Washer	Rondelle	Arandela	Anilha	M16 2
6	4/1601	Washer	Rondelle	Arandela	Anilha	M16 2
7	161/99544	Boss	Bossage	Resalte	Cubo	2
8	7/16010	Screw	Vis	Tornillo	Parafuse	2
9	4/1005	Washer	Rondelle	Arandela	Anilha	M10 4
10	4/1003	Washer	Rondelle	Arandela	Anilha	M10 4
11	9/10001	Bolt	Boulon	Perno	Perno	4
12	73/0051	Bracket	Patte de montage	Escuadra	Suporte	1
13	72/0033	Document Tube	Tube de document	Tubo documento	Tubo de Documento	1
14	981/99968	Plate	Plaque	Placa	Placa	Yanmar 1
14	981/99994	Plate	Plaque	Placa	Placa	Kubota 1
15	981/99916	Throttle Lever	Manette d'accélérateur	Palanca de aceleración	Alavanca do estrangulado	1
16	7/5170	Screw	Vis	Tornillo	Parafuse	4
17	4/5002	Washer	Rondelle	Arandela	Anilha	8
18	8/5003	Nut	Ecrou	Tuerca	Porca	8
19	981/99990	Plate	Plaque	Placa	Placa	1
20	981/99991	Plate	Plaque	Placa	Placa	1
21	7/5171	Screw	Vis	Tornillo	Parafuse	4
22	7/6034	Screw	Vis	Tornillo	Parafuse	6
23	70/0184	Ignition & Key	Ignition & Clavette	Ignición & Chaveta	Ignição & Chave	Yanmar 1
24	70/0273	Ignition & Key	Ignition & Clavette	Ignición & Chaveta	Ignição & Chave	Kubota 1
25	70/0185	Key	Clavette	Chaveta	Chave	Yanmar 1
26	919/99808	Key	Clavette	Chaveta	Chave	Kubota 1

888-634-4289

An iBuy Stores Company

- To see the colour options for this part, please see the 'H' area of the 'Spare Parts Information' section of the Operators Manual.

- To see the colour options for this part, please see the '##' area of the 'Spare Parts Information' section of the Operators Manual.




Handle Assembly, EPA - North America

6-02

1 - ##	981/07100.....	Handle	Guidon	Manillar	Punho	1
2 - ##	981/99992.....	Plate	Plaque	Placa	Placa	1
3	161/99543.....	Bearing	Roulement	Cojinete	Rolamanto	2
4	8/16005.....	Nut	Ecrou	Tuerca	Porca	2
5	05.1.009.....	Washer	Rondelle	Arandela	Anilha	M16.....2
6	4/1601.....	Washer	Rondelle	Arandela	Anilha	M16.....2
7	161/99544.....	Boss	Bossage	Resalte	Cubo	2
8	7/16010.....	Screw	Vis	Tomillo	Parafuse	2
9	4/1005.....	Washer	Rondelle	Arandela	Anilha	M10.....4
10	4/1003.....	Washer	Rondelle	Arandela	Anilha	M10.....4
11	9/10001.....	Bolt	Boulon	Perno	Perno	4
12	73/0051.....	Bracket	Patte de montage	Escuadra	Suporte	1
13	72/0033.....	Document Tube	Tube de document	Tubo documento	Tubo de Documento	1
14	981/99808.....	Plate	Plaque	Placa	Placa	1
15	21/0376.....	Throttle Lever	Manette d'accélérateur	Palanca de aceleración	Alavanca do estrangulado	1
16	9/6003.....	Screw	Vis	Tomillo	Parafuse	M6 x.....2
17	8/6001.....	Nut	Ecrou	Tuerca	Porca	M6.....4
18	7/6039.....	Screw	Vis	Tomillo	Parafuse	M6 x.....2
19	981/99990.....	Plate	Plaque	Placa	Placa	1
20	4/6001.....	Washer	Rondelle	Arandela	Anilha	M6.....4
21	70/0273.....	Ignition & Key	Ignición & Clavette	Ignición & Chaveta	Ignição & Chave	1
22	919/99808.....	Key	Clavette	Chaveta	Chave	1

AltradParts.com
888-634-4289
An iBuy Stores Company



Hydraulic Assembly

7-01


1	7/6032	Screw	Vis	Tornillo	Parafuse	M6 x 12	6
2	5/0091	Seal	Joint d'étanchéité	Obturador	Vedação		2
3	981/01908	Cap	Capuchon	Casquete	Tampa		1
4	981/01914	Gasket	Joint	Junta	Gaxeta		1
5 - #	981/06300	Hydraulic Oil Tank	Réservoir d'huile hydraulique	Depos. de aceite hidraulico	Tanque de óleo Hidráulico		1
6	40/00005	Gauge	Jauge	Calibrar	Ajuizar		1
7	6/5020	Filter	Filtre	Filtro	Filtrante		1
8	6/0252	Adaptor	Adaptateur	Adaptador	Adaptador		2
9	32/0136	Hose	Tuyau	Manguera	Tubagem		1
10	6/0244	Adaptor	Adaptateur	Adaptador	Adaptador		4
11	32/0137	Hose	Tuyau	Manguera	Tubagem		1
12	5/0086	Seal	Joint d'étanchéité	Obturador	Vedação		2
13	6/0254	Adaptor	Adaptateur	Adaptador	Adaptador		2
14	32/0138	Hose	Tuyau	Manguera	Tubagem		1
15	6/0253	Adaptor	Adaptateur	Adaptador	Adaptador		1
16	5/0007	Seal	Joint d'étanchéité	Obturador	Vedação		2
17	6/1147	Adaptor	Adaptateur	Adaptador	Adaptador		1
18	6/0242	Adaptor	Adaptateur	Adaptador	Adaptador		2
19	31/0137	Hose	Tuyau	Manguera	Tubagem		1
20	31/0140	Hose	Tuyau	Manguera	Tubagem		1
21	6/1148	Hydraulic Motor	Moteur Hydraulique	Motor hidráulico	Motor hidráulico		2
22	31/0143	Hose	Tuyau	Manguera	Tubagem		2
23	31/0143	Hose	Tuyau	Manguera	Tubagem		2
24	981/06400	Pipe	Tubo	Pistão	Zuigo		2
25	31/0141	Hose	Tuyau	Manguera	Tubagem		1
26	6/0258	Adaptor	Adaptateur	Adaptador	Adaptador		4
27	6/5021	Filter Element	Élément Filtre	Elemento Filtro	Elemento Filtrante		1

888-634-4289

An iBuy Stores Company

- To see the colour options for this part, please see the '#' area of the 'Spare Parts Information' section of the Operators Manual.

- To see the colour options for this part, please see the '##' area of the 'Spare Parts Information' section of the Operators Manual.




Layshaft Assembly

1	9/8012	Bolt	Boulon	Perno	Perno	M8 x 20	1
2	4/1015	Spacer	Entretoise	Espaciador	Espaçador		1
3	21/0343	Bush	Douille	Buje	Bucha		1
4	981/02404	Pulley	Poulie	Polia	Polia		2
5	7/8012	Screw	Vis	Tornillo	Parafuse	M8 x 25	4
6	4/8006	Washer	Rondelle	Arandela	Anilha	M8	4
7	53/0087	Bearing	Roulement	Cojinete	Rolamanto		2
8	4/8006	Washer	Rondelle	Arandela	Anilha	M8	4
9	8/8008	Nut	Ecrou	Tuerca	Porca	M8	4
10	21/0346	Key	Clavette	Chaveta	Chave		1
11	21/0347	Key	Clavette	Chaveta	Chave		1
12	981/02401	Shaft	Axe	Eje	Veio		1
13	21/0345	Bush	Douille	Buje	Bucha		1
14	21/0342	Clutch	Embrayage	Embrague	Embraiagem		1
15	9/5022	Bolt	Boulon	Perno	Perno	M5	1
16	4/5002	Washer	Rondelle	Arandela	Anilha	M5	2
17	981/99960	Clamp	Bride	Mordaza	Grampo		1
18	8/5003	Nut	Ecrou	Tuerca	Porca	M5	1
19	7/5022	Screw	Vis	Tornillo	Parafuse	M5 x 8	1
20	981/99915	Vibrator Cable	Câble de vibreur	Cable del vibrador	Cabo Vibratória		1
21	7/10005	Screw	Vis	Tornillo	Parafuse	M10 x	1
22	4/1003	Washer	Rondelle	Arandela	Anilha	M10 x	1
23	981/04500	Pin	Goupille	Pasador	Pino		1
24	981/02300	Bracket	Patte de montage	Escuadra	Suporte		1
25	981/02402	Pin	Goupille	Pasador	Pino		1
26	7/8026	Screw	Vis	Tornillo	Parafuse	M8 x 50	1
27	8/8001	Nut	Ecrou	Tuerca	Porca	M8	1
28	961/99925	Spring	Ressort	Resorte	Mola		1
29	2/0010	Clip	Collier	Presilla	Grampo		1

Altradparts.com

888-634-4289

An iBuy Stores Company



Pump Assembly

1	981/02404.....	Pulley.....	Poulie.....	Polia.....	Polia.....	1
2	21/0345.....	Bush.....	Douille.....	Buje.....	Bucha.....	1
3	8/8008.....	Nut.....	Ecrou.....	Tuerca.....	Porca.....	M8.....3
4	981/99917.....	Control Cable.....	Câble de commande.....	Cable de control.....	Cabo de Controle.....	1
5	7/10014.....	Screw.....	Vis.....	Tornillo.....	Parafuse.....	M10 x 30.....2
6	981/03000.....	Support.....	Support.....	Soporte.....	Suporte.....	1
7	6/1147.....	Hydraulic Pump.....	Pompe hydraul.....	Bomba hidráulica.....	Bomba hidráulica.....	1
8	4/1005.....	Washer.....	Rondelle.....	Arandela.....	Anilha.....	M10 x 30.....2
9	8/10006.....	Nut.....	Ecrou.....	Tuerca.....	Porca.....	M10 x 30.....2
10	3/0083.....	Spirol Pin.....	Goupille Spirol.....	Pasador Spirol.....	Pino em Espiral.....	1
11	981/03500.....	Lever.....	Levier.....	Palanca.....	Alavanca.....	1
12	3/5046.....	Joint.....	Joint.....	Junta.....	Junta.....	1
13	8/8001.....	Nut.....	Ecrou.....	Tuerca.....	Porca.....	M8.....1
14	919/01000.....	Shaft.....	Axe.....	Eje.....	Veio.....	1
15	919/99819.....	Boss.....	Bossage.....	Resalte.....	Cubo.....	1
16	919/01101.....	Bracket.....	Patte de montage.....	Escuadra.....	Suporte.....	1
17	7/8037.....	Screw.....	Vis.....	Tornillo.....	Parafuse.....	1
18	2/0061.....	Spring.....	Ressort.....	Resorte.....	Mola.....	1
19	919/99821.....	Boss.....	Bossage.....	Resalte.....	Cubo.....	1
20	8/8001.....	Nut.....	Ecrou.....	Tuerca.....	Porca.....	M8.....2
21	7/8006.....	Screw.....	Vis.....	Tornillo.....	Parafuse.....	M8.....1


Not Shown

-	5/0087.....	Seal Kit.....	Jeu étanchéité.....	Juego retenes.....	Conjunto de Vedação.....	1
-		Hydraulic Pump.....	Pompe hydraul.....	Bomba hidráulica.....	Bomba hidráulica.....	1

AltRadParts.com

888-634-4289

An iBuy Stores Company



Water Tank Assembly


10-01

1	981/02501.....	Water Tank	Réservoir d'eau.....	Depos. de agua.....	Tanque de água.....	1	
2	6/0233	Adaptor	Adaptateur	Adaptador	Adaptador	2	
3	981/02502.....	Hose.....	Tuyau.....	Manguera.....	Tubagem	1	
4	10-601-0800.....	Bung.....	Obturateur	Tapón	Tampão	1	
5	5/0085	Seal.....	Joint d'étanchéité	Obturator	Vedação	5	
6	7/10005.....	Screw.....	Vis	Tornillo	Parafuse	M10 x 25	1
7	4/1003	Washer.....	Rondelle	Arandela.....	Anilha	M10	1
8	50/000071.....	Spacer.....	Entretoise.....	Espaciador	Espaçador	1	1
9	4/1005	Washer.....	Rondelle	Arandela.....	Anilha	M10	1
10	151/99963.....	Cap	Capuchon	Casquete.....	Tampa	1	1
11	6/0237	Adaptor	Adaptateur	Adaptador	Adaptador	2	2
12	6/0238	Adaptor	Adaptateur	Adaptador	Adaptador	2	2
14	6/0236	Adaptor	Adaptateur	Adaptador	Adaptador	2	2
15	6/0235	Adaptor	Adaptateur	Adaptador	Adaptador	4	4
16	981/04700.....	Pipe	Tubo.....	Pistão	Zuiger	2	2
17	6/2022	Adaptor	Adaptateur	Adaptador	Adaptador	4	4
18	8/5003	Nut	Ecrou	Tuerca	Porca	M5	4
19	3/7059	Clamp.....	Bride	Mordaza	Grampo	4	4
20	7/5023	Screw.....	Vis	Tornillo	Parafuse	M5 x 15	4
21	32/0141.....	Hose.....	Tuyau.....	Manguera.....	Tubagem	2	2
22	32/0140.....	Hose.....	Tuyau.....	Manguera.....	Tubagem	1	1
23	32/0139.....	Hose.....	Tuyau.....	Manguera.....	Tubagem	1	1

AltradParts.com

888-634-4289

An iBuy Stores Company




Hourmeter

11-01

1	7/3010	Screw.....	Vis	Tornillo	Parafuse	M3 x 20	2
2	100/02400	Hourmeter	Compteur horaire	Cuenta horas	Horímetro		1
3	8/3002	Nut	Ecrou	Tuerca	Porca	M3	2
4	71/0274	Harness.....	Faisceau	Arnés	Arnés		1

AltradParts.com
888-634-4289
An iBuy Stores Company



Decals

1	800/99517	Decal	Autocollant	Rótulo	Decalque	TDX 650A	1
2	800/99526	Decal	Autocollant	Rótulo	Decalque	TDX 650A	1
3	800/99514	Decal	Autocollant	Rótulo	Decalque	TDX 650A	1
4	800/99515	Decal	Autocollant	Rótulo	Decalque	TDX 650A	1
5	800/99682	Decal	Autocollant	Rótulo	Decalque	Vibration Lever	1
6	800/99990	Decal	Autocollant	Rótulo	Decalque	Read Manual	1
7	800/99681	Decal	Autocollant	Rótulo	Decalque	Forward / Reverse	1
8	800/99676	Decal	Autocollant	Rótulo	Decalque	Service Canopy	1
9	800/99686	Decal	Autocollant	Rótulo	Decalque	Strapping Points	4
10	800/99801	Decal	Autocollant	Rótulo	Decalque	Hot Parts	1
11	800/99685	Decal	Autocollant	Rótulo	Decalque	Yanmar Engine Oil Fill	1
11	800/99553	Decal	Autocollant	Rótulo	Decalque	Kubota Engine Oil Fill	1
12	800/99675	Decal	Autocollant	Rótulo	Decalque	Hydraulic Oil Level	1
13	800/99684	Decal	Autocollant	Rótulo	Decalque	Engine Oil Type	1
14	800/99687	Decal	Autocollant	Rótulo	Decalque	Water Tank Drain	1
15	800/99680	Decal	Autocollant	Rótulo	Decalque	Park Brake	1
16	800/99679	Decal	Autocollant	Rótulo	Decalque	Spraybar Tap	1
17	800/99673	Decal	Autocollant	Rótulo	Decalque	Diesel Only	1
18	800/99674	Decal	Autocollant	Rótulo	Decalque	Hydraulic Oil Fill	1
19	800/99986	Decal	Autocollant	Rótulo	Decalque	Lifting Point	1
20	800/99678	Decal	Autocollant	Rótulo	Decalque	Ignition Key (Yanmar)	1
20	800/99516	Decal	Autocollant	Rótulo	Decalque	Ignition Key (Kubota)	1
21	800/99677	Decal	Autocollant	Rótulo	Decalque	Throttle Lever	1
22	19.0.373	Decal	Autocollant	Rótulo	Decalque	Caution - Safety	1
23	800/99942	Decal	Autocollant	Rótulo	Decalque	107 dB(A)	1
24	800/99521	Decal	Autocollant	Rótulo	Decalque	Exhaust Fumes	1
25	800/99802	Decal	Autocollant	Rótulo	Decalque	Caution - Crushing	1

Altradparts.com

888-634-4289

An iBuy Stores Company

AltradParts.com

888-634-4289

An iBuy Stores Company