



SERVICE / PARTS MANUAL

MODELS: WolfPac™ 6400B




ASPHALT ROLLER

A 100% employee-owned American manufacturer

4. PARTS LIST

4.3 Drums



March 2003

H0105-0-2


4. PARTS LIST

4.3 Drums

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	62809	Screw	6
2	62808	Retainer	2
3	62807	Bearing	4
4	62810	Spacer	4
6	63861	Bearing	4
7	62800	Retainer	4
8	62802	Seal	4
9	70597	Capscrew	1
10	62803	Retainer	4
11	70113	Bolt	24
12	70428	Lock Washer	24
13	62553	Seal	2
14	62806	Housing	2
15	62801	Circlip	4
16	62820	Coupling	2
17	62556	Key	2
19	62805	Vibrator Shaft	2
20	62819	Capscrew	2
21	62296	Housing	2
22	62796	Retainer	2
24	62804	Drum	2
25	63862	Grease	1

4. PARTS LIST

4.4 Vibrator Leg



March 2001

H0105-0-4


4. PARTS LIST

4.4 Vibrator Leg

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	62500	Setscrew	4
2	63863	Spacer	4
3	63864	Hose Clamp	2
5	63865	Support Leg	2
6	63866	Extension Block	4
7	63867	Capscrew	16
9	63868	Nord-Lock Washer	32
10	63869	Nut	16
11	62521	Bolt	4
12	70638	Setscrew	4
13	62545	Washer	4
14	62816	Plate	2
15	62821	Seal	2
16	70431	A.V. Mount	16
17	70604	Washer	32
18	70117	Nut	32
19	70754	Washer	8
20	70704	Capscrew	8
21	62818	Spacer	2
22	62817	Coupling	2
23	62814	Kit	2
24	62815	Hydraulic Motor	2

4. PARTS LIST

4.5 Drive Leg



March 2001

H0105-0-6


4. PARTS LIST

4.5 Drive Leg

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	70604	Washer	32
2	62545	Washer	32
3	70748	Setscrew	32
4	62544	A. V. Mount	16
5	62600	Washer	16
6	70684	Nut	16
7	63866	Extension Block	4
8	62521	Bolt	4
9	63869	Nut	16
10	63868	Nord-Lock Washer	32
11	63867	Capscrew	16
13	63870	Hose Clamp	2
14	62500	Setscrew	4
15	63863	Spacer	4
16	63871	Support Leg	2
17	62825	Kit	2
18	62826	Hydraulic Motor	2
19	62824	Setscrew	12
20	70752	Washer	12
21	70690	Washer	12
22	70684	Nut	12
23	62827	Plate	2
24	62822	Washer	10

4. PARTS LIST

4.6 Front Frame



March 2003

H0105-0-8


4. PARTS LIST

4.6 Front Frame

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	63872	Bonnet	1
3	62830	Handle	1
4	70784	Schnoor Washer	2
5	62831	Capscrew	2
6	70620	Nut	2
7	70301	Washer	2
8	62835	Buffer	2
9	70620	Nut	4
10	70301	Washer	2
11	62498	Cap	1
12	62828	Manual Holder	1
13	62848	Panel	1
15	63873	Frame	1
17	63874	Panel	1
19	70182	Washer	4
20	70128	Spring Washer	4
21	70159	Setscrew	4
22	62496	Lock	1
23	70116	Spring Washer	2
24	70132	Setscrew	2
25	62849	Panel	1
27	70128	Spring Washer	8
28	62850	Setscrew	8
29	70538	Nut	2
30	70122	Washer	2
31	70596	Setscrew	2
32	62499	Gas Strut	2
33	70538	Nut	2
34	70152	Washer	2
35	62500	Setscrew	2
36	70301	Washer	4
37	62831	Capscrew	4
38	63877	Blanking Grill	2
39	62490	Seal	1
40	63875	Hinge	1
41	70740	Setscrew	6
42	70754	Schnoor Washer	6
43	70122	Washer	6
44	62854	Bolt	2
45	70604	Washer	2
46	70117	Nut	2
47	63876	Hinge	1
48	62857	Hinge	2

4. PARTS LIST

4.7 Rear Frame



March 2003

H0105-0-12


4. PARTS LIST

4.7 Rear Frame

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	62836	Mat	1
3	62846	Footplate	1
5	62845	Plate	1
7	70263	Washer	4
8	70217	Setscrew	4
9	63877	Blanking Grill	2
10	70301	Washer	4
11	62831	Capscrew	4
12	62842	Crossmember	1
14	70159	Setscrew	4
15	70604	Washer	4
16	62500	Setscrew	2
17	70122	Washer	2
19	64137	Rear Frame	1
21	62914	A.V. Mount	4
22	70182	Washer	4
23	70117	Nut	4

4. PARTS LIST

4.8 Center Pivot



March 2001

H0105-0-14



4. PARTS LIST

4.8 Center Pivot

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	63878	Cover	1
2	63195	Clip	1
3	63879	Nut	1
4	63880	Washer	1
5	63881	Spacer	1
6	63882	Retainer	1
7	63883	Bearing	1
8	62841	Bolt	4
9	62869	Spring Washer	4
10	62870	Washer	4
11	70623	Nut	4
12	63884	Seal	1
13	63881	Spacer	1
14	63885	Center Pivot Pin	1
15	63881	Spacer	1
16	63884	Seal	1
17	63886	Bearing	1
18	62862	Hose	1
19	62872	Union	1
20	63879	Nut	1
21	63880	Washer	1
22	63886	Bearing	1
23	62873	Adaptor	1
24	62864	Hose	1
25	63887	Rear Link Pivot Pin	1
26	62678	Grease Nipple	1
27	63888	Cover	1
28	63195	Clip	1
29	62878	Split Pin	1
30	63889	Slotted Nut	1
31	63890	Washer	1
32	63891	Link Plate	1
33	63892	Rear Center Pivot Bracket	1
34	70117	Nut	4
35	70309	Washer	4
36	63893	Counter Sunk Bolt M10 x 70	4
37	63894	Bush	1
38	63895	Retainer Bearing	1
39	63896	Front Center Pivot Bracket	1
40	63897	Grease Nipple	2
41	63898	Durlock Bolt	11

4. PARTS LIST

4.9 Articulation Lock



March 2001

H0105-0-18


4. PARTS LIST

4.9 Articulation Lock

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	70786	Cap	3
2	62678	Grease Nipple	3
3	62860	Adaptor	3
4	70309	Washer	3
5	62861	Nut	3
6	62862	Hose	1
8	62863	Hose	1
10	62864	Hose	1
12	62883	Pin	2
13	62502	Clip	2
14	63899	Articulation Lock	1

4. PARTS LIST

4.10 Seat Support



March 2003

H0105-0-20


4. PARTS LIST

4.10 Seat Support

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	62885	Cover	1
2	62510	Setscrew	6
3	70784	Schnoor Washer	6
4	70301	Washer	6
5	62886	Gasket	1
6	63900	Foam Seal	1
7	62514	Armrest	1
8	70301	Washer	4
9	70620	Nut	4
10	63901	Cap	1
11	63902	Sealing Strip	1
12	63902	Sealing Strip	1
13	62889	Vandal Cover Holder	1
14	70301	Washer	2
15	70784	Schnoor Washer	2
16	70183	Setscrew	2
17	62515	Seat	1
18	70159	Setscrew	1
19	70309	Washer	3
20	70117	Nut	1
21	62516	Seat Belt Kit	1
22	70117	Nut	1
23	70604	Washer	3
24	70159	Setscrew	1
26	70309	Washer	4
27	62545	Schnoor Washer	4
28	70159	Setscrew	4
29	70645	Capscrew	4
30	70116	Spring Washer	4
38	63903	Rear Panel	1
40	62894	Cover	1
41	70125	Setscrew	1
42	70122	Washer	4
43	70431	A.V. Mount	4
44	70182	Washer	4
45	70309	Washer	4
46	70117	Nut	4
47	63904	Seat Support	1
49	63905	Cable Gland	1
50	63906	Arm	1
51	62896	Cover	1
52	63907	Washer	5

4. PARTS LIST

4.10 Seat Support Continued



March 2003

H0105-0-20


4. PARTS LIST

4.10 Seat Support Continued

ITEM	PART NO.	DESCRIPTION	QUANTITY
53	70784	Schnoor Washer	5
54	62510	Setscrew	5
55	70801	Setscrew	3
56	70784	Schnoor Washer	3
57	62897	Cover	1
58	62898	Hose Clip	2
59	62899	Hose	1
60	62510	Setscrew	4
61	70784	Schnoor Washer	4
62	70808	Washer	4
63	62900	Cover	1
64	62508	Cable	1
65	62511	Setscrew	2
66	70301	Washer	4
67	70298	Nut	2
68	70784	Schnoor Washer	2
69	62902	Grommet	1
70	62901	Cover	1

4. PARTS LIST

4.11 Control & Throttle Lever to February 2003



March 2001

H0105-0-24


4. PARTS LIST

4.11 Control & Throttle Lever to February 2003

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	63908	Switch	1
2	63909	Control Lever	1
3	70801	Setscrew	4
4	70784	Washer	4
5	63910	Screw	2
6	63911	Throttle Lever	1
7	63912	Knob	1
8	70620	Nut	1
9	63913	Cover	2
10	63914	Throttle Cable	1
11	63915	Bracket	1
12	63916	Bracket	1
13	70620	Nut	1
14	70784	Washer	2
15	70123	Setscrew	2
16	63917	Cable	2
17	63918	Fork End	1

4. PARTS LIST

4.12 Control & Throttle Lever from February 2003



March 2003

H0105-0-26


4. PARTS LIST

4.12 Control & Throttle Lever from February 2003

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	63908	Switch	1
2	63919	Control Lever	1
3	70801	Setscrew	4
4	70784	Schnoor Washer	4
5	63910	Screw	2
6	63911	Throttle Lever	1
7	63912	Knob	1
8	70620	Nut	1
9	63913	Cover	1
10	63914	Throttle Cable	1
11	63915	Bracket	1
12	63916	Bracket	1
13	70620	Nut	1
14	70784	Schnoor Washer	2
15	70123	Setscrew	2
16	63920	Control Cable	1
17	63918	Fork End	1

4. PARTS LIST

4.13 Control Lever to February 2003



March 2001

H0105-0-28


4. PARTS LIST

4.13 Control Lever to February 2003

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	63921	Bellows	1
2	63908	Switch	1
3	63922	Handle	1
4	63923	Casing	1
5	63924	Selector Gate	1
6	63925	Switch	2
7	63926	Washer	1

4. PARTS LIST

4.14 Engine



March 2001

H0105-0-30


4. PARTS LIST

4.14 Engine

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	63927	Engine	1
2	62489	Washer	4
3	70754	Washer	4
4	70727	Capscrew	4
5	63928	Edge Protection	0
6	63929	Air Duct	1
7	70183	Setscrew	4
8	70631	Spring Washer	4
9	70808	Washer	4
10	63930	Cover	1
11	63931	Edge Protection	0
12	70117	Nut	6
13	70604	Washer	8
14	62914	A. V. Mount	2
15	62913	Bracket	2
16	62912	Setscrew	2
17	63928	Edge Protection	0
18	70117	Nut	2
19	70604	Washer	2
20	62914	A.V. Mount	2
21	63933	Oil Cooler	1
22	63934	Panel	1
23	70129	Setscrew	2
24	70754	Washer	2
25	62489	Washer	2
26	62600	Washer	2
27	70752	Washer	2
28	70680	Bolt	2
29	62930	Clip	2
30	63935	Hose	1
31	62933	Filter Element	1
32	62932	Filter Element	1
33	62928	Valve	1
34	63936	Hose Clip	2
35	62931	Air Filter	1
36	62934	Elbow	1
37	70681	Bolt	2
38	70752	Washer	2
39	62844	Washer	2
40	62921	Union	1
41	63937	Hose	1
42	70590	Union	1
43	63938	Adaptor	1

4. PARTS LIST

4.14 Engine Continued



March 2001

H0105-0-30


4. PARTS LIST

4.14 Engine Continued

ITEM	PART NO.	DESCRIPTION	QUANTITY
44	70122	Washer	2
45	70496	Setscrew	2
46	70145	Plug	1
47	70577	Seal	2
48	70684	Nut	2
49	62600	Washer	4
50	70752	Washer	2
51	70693	Bolt	2
52	70687	Bolt	6
53	63939	Bracket	1
54	62679	Bolt	12
55	62545	Schnoor Washer	12
56	70604	Washer	12
57	63940	Coupling	1
58	62907	Exhaust Pipe	1

4. PARTS LIST

4.15 Fuel Tank



March 2001

H0105-0-34


4. PARTS LIST

4.15 Fuel Tank

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	62946	Hose	1
2	62944	Clip	2
3	62943	Union	1
4	70129	Setscrew	4
5	70122	Washer	4
6	62949	Gauge	1
7	63941	Fuel Tank Cap	1
8	63942	Fuel Strainer	1
9	63943	Filler Neck	1
10	63944	A.V. Mount	2
11	70264	Washer	2
12	70125	Setscrew	2
13	63945	Support Mat	1
14	70145	Plug	1
15	70577	Seal	1
16	63946	Fuel Tank	1
17	63947	Gasket	1
18	70577	Seal	1
19	62957	Pipe	1
20	62958	Pipe	1
21	63948	Suction Plate	1

4. PARTS LIST

4.16 Water System



March 2001

H0105-0-36


4. PARTS LIST

4.16 Water System

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	70161	Tee	4
2	70776	Clip	22
3	70434	Socket	4
4	62902	Valve	1
5	62959	Socket	1
6	63949	Pump	1
7	62961	Elbow	1
8	63950	Setscrew	4
9	70784	Washer	4
10	70301	Washer	4
11	62570	Pin	1
12	62963	Water Tank	1
14	63951	Water Tank Cap	1
15	70379	Filter	1
16	63952	Washer	1
17	70577	Seal	1
18	70778	Elbow	2
19	62580	Coupling	1
20	62966	Support	1
22	70574	Bearing	2
23	62964	Handle	1
24	70631	Spring Washer	4
25	70123	Setscrew	4
26	62962	Filter	1
27	63953	Screw	2
28	63954	Washer	2
29	70806	Washer	2
30	62965	Rod	1
32	62571	Screw	1
33	70806	Washer	1
34	62569	Lever	1
35	62568	Tap	1
36	70577	Seal	2
37	70520	Union	1
38	62844	Washer	4
39	70217	Setscrew	4
40	70743	Bolt	A/R
41	70116	Spring Washer	A/R
42	70122	Washer	A/R
43	70538	Nut	A/R
45	62971	Plate	4
47	62972	Scraper Blade	4
48	62679	Bolt	4

4. PARTS LIST

4.16 Water System Continued



March 2001

H0105-0-36


4. PARTS LIST

4.16 Water System Continued

ITEM	PART NO.	DESCRIPTION	QUANTITY
49	70604	Washer	4
50	63955	Bush	4
51	70603	Bolt	4
52	62545	Washer	4
53	70604	Washer	4
54	63956	Clamp Boss	4
56	63957	Scraper Bar	2
58	70383	Water Tap	1
59	62969	Plug	1
60	62584	Plug	4
61	63958	Plug	4
63	63959	Scraper Bar	2
65	70538	Nut	A/R
66	70122	Washer	A/R
67	70116	Spring Washer	A/R
68	70743	Bolt	A/R
69	63960	Capscrew	8
70	70784	Washer	16
71	63961	Clamp	8
72	70798	Capscrew	8
73	63962	Spacer Plate	8
75	63963	Spray Bar	2
76	63964	Straight Socket	2
77	70514	Hose Clip	4
79	62980	Spray Bar	2
80	62912	Setscrew	6
81	62668	Clamp	6
82	63902	Sealing Strip	8
83	63966	Spray Nozzle	8
84	70279	Hose	A/R

4. PARTS LIST

4.17 Hydraulic Tank



March 2003

H0105-0-42


4. PARTS LIST

4.17 Hydraulic Tank

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	63967	Filter Assembly	1
2	63968	Gauge	1
3	70748	Setscrew	2
4	70604	Washer	2
5	63222	Breather	1
6	63202	Filter	1
7	63969	Gasket	1
8	70122	Washer	4
9	70129	Setscrew	4
10	63970	Suction Plate	1
11	63192	Gauge	1
12	70125	Setscrew	2
13	70264	Washer	2
14	63944	A. V. Mount	2
15	62500	Setscrew	2
16	70754	Washer	2
17	70122	Washer	2
18	63971	Plate	1
20	63941	Fuel Tank Cap	1
21	63942	Fuel Strainer	1
22	63943	Filler Neck	1
23	63945	Support Mat	1
24	70145	Plug	1
25	70577	Seal	1
26	63972	Hydraulic Tank	1
27	63973	Gasket	1
28	63974	Filter Element	1

4. PARTS LIST

4.18 Hydraulic Tank Hoses



March 2001

H0105-0-44


4. PARTS LIST

4.18 Hydraulic Tank Hoses

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	63975	Hydraulic Hose	1
2	63234	Tee	1
3	63976	Hydraulic Hose	1
4	63236	Seal	1
5	63235	Union	1
6	63977	Hydraulic Hose	1
8	63978	Hydraulic Hose	1
9	70584	Union	1
10	70585	Seal	1

4. PARTS LIST

4.19 Drive Pump



March 2001

H0105-0-46


4. PARTS LIST

4.19 Drive Pump

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	63979	Hydraulic Hose	1
3	62639	Tee	1
4	63265	Test Point	1
5	63980	Union	1
6	63981	Seal	1
7	70129	Setscrew	2
8	70122	Washer	2
9	70538	Nut	2
10	63982	Lever	1
11	63983	Seal Kit	1
12	63984	Washer	2
13	62822	Washer	2
14	63253	Bolt	2
15	62608	Seal	1
16	63985	Union	1
17	63986	Hydraulic Hose	1
18	63987	Hydraulic Hose	1
20	70520	Union	1
21	70577	Seal	1
22	63988	Seal	2
23	63989	Union	2
24	70585	Seal	2
25	63990	Union	2
26	63991	Test Point	2
27	63992	Hydraulic Hose	1
29	63993	Hydraulic Hose	1
31	63994	Hydraulic Hose	1
33	63995	Capscrew	16
34	70128	Spring Washer	16
35	63978	Hydraulic Hose	1
37	63996	Union	1
38	63997	Hydraulic Hose	1
39	63267	Hydraulic Pump	1
40	70577	Seal	1
41	70764	Union	1
42	63998	Hydraulic Hose	1
44	63999	Seal Kit	1
45	70726	Capscrew	2
46	62545	Washer	2
47	70604	Washer	2
48	70577	Seal	1
49	70590	Union	1
50	63976	Hydraulic Hose	1

4. PARTS LIST

4.20 Tow Valve



March 2003

H0105-0-50


4. PARTS LIST

4.20 Tow Valve

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	76972	Bolt	2
2	70754	Washer	2
3	70122	Washer	2
4	64000	Tow Valve	1
5	62615	Seal	1
6	62616	Union	1
7	62639	Tee	1
8	64001	Hydraulic Hose	1
10	64002	Hydraulic Hose	1
12	64003	Seal Kit	1
13	62615	Seal	1
14	62616	Union	1
15	63979	Hydraulic Hose	1
17	63247	Union	1
18	64004	Hydraulic Hose	1
20	70581	Seal	1
21	62615	Seal	1
22	62616	Union	1
23	64005	Hydraulic Hose	1

4. PARTS LIST

4.21 Vibrator Pump



March 2001

H0105-0-52


4. PARTS LIST

4.21 Vibrator Pump

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	64006	Hydraulic Hose	1
2	64007	Adaptor	1
3	70590	Union	1
4	70577	Seal	1
5	63975	Hydraulic Hose	1
6	70584	Union	1
7	70585	Seal	1
8	63230	Hydraulic Pump	1
9	64008	Seal Kit	1
10	62819	Capscrew	2
11	62545	Washer	2
12	70309	Washer	2

4. PARTS LIST

4.22 Manifold Block




4. PARTS LIST

4.22 Manifold Block

ITEM	PART NO.	DESCRIPTION	QUANTITY
21	70590	Union	1
22	64009	Hydraulic Hose	1
23	62615	Seal	1
24	64010	Plug	1
25	64011	Hydraulic Hose	1
26	62616	Union	1
27	62615	Seal	1
28	63225	Manifold	1
29	70264	Washer	1
30	70754	Washer	1
31	70125	Setscrew	1
32	62615	Seal	1
33	62616	Union	1
34	64004	Hydraulic Hose	1
35	64012	Hydraulic Hose	1
36	62616	Union	1
37	62615	Seal	1

4. PARTS LIST

4.23 Oil Cooler



March 2001

H0105-0-56


4. PARTS LIST

4.23 Oil Cooler

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	63977	Hydraulic Hose	1
2	64014	Hydraulic Hose	1
3	63235	Union	1
4	63236	Seal	1
5	64009	Hydraulic Hose	1
7	63986	Hydraulic Hose	1
8	64014	Hydraulic Hose	1
10	63234	Tee	1
11	63235	Union	1
12	63236	Seal	1

4. PARTS LIST

4.24 Steering



March 2001

H0105-0-58


4. PARTS LIST

4.24 Steering

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	64005	Hydraulic Hose	1
3	70576	Union	1
4	70577	Seal	4
5	62652	Steering Column	1
6	64016	Nut	1
7	62651	Cover	1
8	62650	Knob	1
9	62658	Push Button	1
10	62657	Steering Wheel	1
11	70739	Setscrew	4
12	62545	Washer	4
13	70604	Washer	4
14	62661	Bush	1
15	64017	Ram Pin	1
16	62678	Grease Nipple	1
17	62872	Union	1
18	63186	Pin	1
19	63185	Bush	2
20	64018	Hydraulic Hose	1
22	70620	Nut	1
23	70264	Washer	2
24	62669	Clamp	2
25	70742	Bolt	1
27	64005	Hydraulic Hose	1
28	62639	Tee	1
29	62616	Union	1
30	62615	Seal	1
31	64019	Seal Kit	1
32	63184	Washer	1
33	63183	Nut	1
34	64020	Hydraulic Ram	1
35	64021	Hydraulic Hose	1
37	64022	Bush	1
38	63784	Washer	1
39	63183	Nut	1
40	62991	Cover	1
41	62617	Clip	2
42	76737	Seal Kit	1
43	62986	Orbitrol	1
44	62655	Cover	1
45	62653	Union	2
46	70764	Union	1
47	63998	Hydraulic Hose	1

4. PARTS LIST

4.25 Vibrator Valve



March 2001

H0105-0-62


4. PARTS LIST

4.25 Vibrator Valve

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	64006	Hydraulic Hose	1
2	70590	Union	4
3	70577	Seal	4
4	64023	Seal Kit	1
5	64024	Hydraulic Hose	1
7	70538	Nut	2
8	62489	Washer	4
9	63181	Bracket	1
10	64025	Hydraulic Hose	1
12	70590	Union	2
13	70577	Seal	2
14	62645	Valve	1
15	70596	Setscrew	2
16	64138	Hydraulic Hose	1
18	62643	Tee	1
19	64026	Hydraulic Hose	1
21	64027	Valve	1
22	62489	Washer	2
23	70754	Washer	2
24	70598	Bolt	2
25	64015	Hydraulic Hose	1

4. PARTS LIST

4.26 Front Vibrator Hoses



March 2001

H0105-0-64


4. PARTS LIST

4.26 Front Vibrator Hoses

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	70120	Bolt	2
2	70754	Washer	2
3	64028	Plate	1
4	64029	Hose Clamp	2
6	64030	Hydraulic Hose	1
8	64031	Hydraulic Hose	1
10	64032	Hydraulic Hose	1
11	62643	Tee	1
12	64033	Union	1
13	64014	Hydraulic Hose	1
15	64011	Hydraulic Hose	1
16	62639	Tee	1
17	64139	Hydraulic Hose	1
19	64034	Hydraulic Hose	1
22	64030	Hydraulic Hose	1
23	70590	Union	1
24	70577	Seal	1
25	62616	Union	1
26	62615	Seal	1
27	70577	Seal	1
28	70590	Union	1

4. PARTS LIST

4.27 Rear Vibrator Hoses



March 2001

H0105-0-66


4. PARTS LIST

4.27 Rear Vibrator Hoses

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	70120	Bolt	2
2	70754	Washer	2
3	64028	Plate	1
4	64029	Hose Clamp	2
6	64030	Hydraulic Hose	1
8	64031	Hydraulic Hose	1
9	62643	Tee	1
10	64025	Hydraulic Hose	1
12	64034	Hydraulic Hose	1
14	64035	Nut	1
15	63162	Union	1
16	64012	Hydraulic Hose	1
18	64037	Hydraulic Hose	1
20	62635	Tee Piece	1
21	64038	Hydraulic Hose	1
23	64024	Hydraulic Hose	1
25	64039	Hydraulic Hose	1
27	70590	Union	1
28	70577	Seal	1
29	62616	Union	1
30	62615	Seal	1
31	70577	Seal	1
32	70590	Union	1

4. PARTS LIST

4.28 Front Drive



March 2001

H0105-0-68


4. PARTS LIST

4.28 Front Drive

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	70120	Bolt	2
2	70754	Washer	2
3	64041	Panel	1
4	64042	Hose Clamp	2
5	63993	Hydraulic Hose	1
8	64001	Hydraulic Hose	1
10	64043	Hydraulic Hose	1
11	64139	Hydraulic Hose	1
14	63987	Hydraulic Hose	1
16	64044	Hydraulic Hose	1
18	64045	Hydraulic Hose	1
19	62615	Seal	1
20	62616	Union	1
22	64044	Hydraulic Hose	1
23	70590	Union	1
24	70577	Seal	1
25	63240	Union	1
26	70581	Seal	1
27	70590	Union	1
28	70577	Seal	1

4. PARTS LIST

4.29 Rear Drive



March 2001

H0105-0-70


4. PARTS LIST

4.29 Rear Drive

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	70120	Bolt	2
2	70754	Washer	2
3	64041	Panel	1
4	64042	Hose Clamp	2
5	63994	Hydraulic Hose	1
7	64002	Hydraulic Hose	1
9	64037	Hydraulic Hose	1
11	63992	Hydraulic Hose	1
14	64044	Hydraulic Hose	1
16	64045	Hydraulic Hose	1
18	64043	Hydraulic Hose	1
19	62615	Seal	1
20	62616	Union	1
22	64044	Hydraulic Hose	1
23	70590	Union	1
24	70577	Seal	1
25	63240	Union	1
26	70581	Seal	1
27	70590	Union	1
28	70577	Seal	1

4. PARTS LIST

4.30 Clamps



March 2001

H0105-0-72


4. PARTS LIST

4.30 Clamps

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	70716	Bolt	3
2	70784	Washer	9
3	62668	Clamp	3
4	64046	Bolt	2
5	62670	Plate	6
6	62669	Clamp	6
7	62665	Stacking Bolt Stauff	2
8	64047	Clamp	9
9	62666	Stacking Bolt Stauff	3
10	70742	Bolt	4
11	70816	Bolt	5
12	70754	Washer	5
13	62664	Plate	5
14	64048	Bracket	1
15	62489	Washer	1
16	70256	Hose Clip	1
17	70148	Setscrew	1
18	70264	Washer	2
19	64049	Hose Clip	1
20	70538	Nut	1
21	64050	Bracket	1
22	64051	Clamp	1

4. PARTS LIST

4.31 Electrics



March 2003

H0105-0-76


4. PARTS LIST

4.31 Electrics

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	70129	Setscrew	1
2	70122	Washer	1
3	70538	Nut	1
4	62730	Horn	1
5	62746	Key	1
6	62745	Battery Isolator	1
7	64052	Battery Lead	1
8	70123	Setscrew	2
9	70301	Washer	2
10	70620	Nut	2
11	64053	Wiring Harness	1
12	75759	Switch	1
13	64054	Bracket	1
14	70182	Washer	2
15	62545	Schooner Washer	2
16	70127	Bolt	2
17	64055	Audible Warning	1
18	70538	Nut	2
19	62489	Washer	2
20	70129	Setscrew	2
21	76758	Bracket	1
22	64056	Battery	1
23	76750	Battery Lead	1
24	64057	Foam Packer	1
25	76749	Battery Lead	1
26	76748	Strap	1
27	70122	Washer	2
28	70129	Setscrew	2

4. PARTS LIST

4.32 Control Panel



March 2001

H0105-0-78


4. PARTS LIST

4.32 Control Panel

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	62704	Grommet	15
2	70808	Washer	4
3	70784	Washer	4
4	70123	Setscrew	4
5	76763	Plate	1
6	62717	Flasher Unit	1
7	70811	Washer	1
8	62724	Screw	1
9	62722	Capacitor	1
10	62721	Clip	1
11	76765	Connector	1
12	76764	Screw	1
13	70811	Washer	3
14	62724	Screw	3
15	62723	Relay	3
16	64058	Wiring Harness	1
17	62703	Timer	1
18	76769	Relay	1
19	62708	Connector	1
20	62710	Plate	1
21	62712	Diode	2
22	62711	Diode	1
23	76766	Wiring Harness	1
24	64060	Wiring Harness	1
25	62716	Relay	3
26	62707	Relay	7
27	62705	Relay	7
28	64061	Resistor	1
29	62715	Relay Base	3
30	76770	Rail	1
31	62724	Screw	2
32	70811	Washer	2

4. PARTS LIST

4.33 Dashboard



March 2001

H0105-0-80


4. PARTS LIST

4.33 Dashboard

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	62685	Push Button	1
2	62680	Contact Block	1
3	70819	Hourmeter	1
4	70820	Rivet	2
5	62688	Rivet	4
6	62607	Lamp	2
7	64062	Potentiometer	1
8	64063	Plug	1
9	62695	Knob and Holder	1
10	62690	Switch	1
11	62691	Lamp	1
12	62692	Contact Block	1
13	62683	Contact Block	1
14	62683	Contact Block	1
15	64064	Cap	1
16	62693	Push Button	1
17	62681	Circuit Breaker	1
18	62697	Pin	1
19	70301	Washer	1
20	70784	Washer	1
21	70759	Setscrew	1
22	62686	Circuit Breaker	1
23	62701	Wiring Harness	1
24	64065	Wiring Harness	1
25	64066	Wiring Harness	1
26	62682	Switch	1
27	62691	Lamp	1
28	62683	Contact Block	1
29	62692	Contact Block	1
30	62680	Contact Block	1
31	76761	Gasket	1
32	70301	Washer	5
33	62510	Setscrew	5
34	62680	Contact Block	1
35	62683	Contact Block	1
36	76762	Plate	1
37	62684	Ignition Switch	1
38	76740	Key	-

4. PARTS LIST

4.34 ROPS



March 2001

H0105-0-86


4. PARTS LIST

4.34 ROPS

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	64086	Bolt	2
2	70808	Washer	2
3	70620	Nut	2
4	64087	Cover	1
5	64088	ROPS	1
7	64089	Locking Pin	2
8	70623	Nut	2
9	70745	Washer	4
10	64090	Bolt	2
11	62841	Bolt	8
12	70745	Washer	16
13	70623	Nut	8
14	64091	ROPS	1

4. PARTS LIST

4.35 Decal Identification



March 2003

H0105-0-92

4. PARTS LIST

4.35 Decal Identification

ITEM	PART NO.	DESCRIPTION	QUANTITY
1	64096	Transfer Control Lever	1
2	62786	Transfer Sit Down	1
3	64097	Transfer Safe Operation	1
4	76773	Transfer Lubrication	1
5	64098	Transfer Throttle Lever	1
6	64099	Transfer Standard	1
7	64100	Transfer RTA Lights	1
8	64101	Transfer Site Lights	1
9	64102	Transfer Tow Warning	1
10	64103	Transfer Seat Adjust.	1
11	64104	Transfer Folding ROPS	1
12	76778	Transfer Water Lever	1
13	76783	Transfer Vibration Lever	1
14	70830	Transfer Hydraulic Oil	1
21	62780	Transfer Anti Crush	2
24	76785	Transfer Fan Warning	1
25	62784	Transfer Tie Down	4
26	64106	Transfer Noise Level	1
28	76786	Transfer Lift Point	4
29	76897	Transfer Hose Tighten	1
31	64107	Transfer Towing Instructions	1
32	70541	Transfer Diesel Oil	1