




05-20HE-850-06SPS




DRIVE TRANSMISSION ASSEMBLY




FRAME-HOPPER ASSEMBLY




REAR WHEEL ASSEMBLY




AUGER ASSEMBLY




BELT GUARD ASSEMBLY




FRONT WHEEL ASSEMBLY




BATTERY BOX ASSEMBLY




FRAME-HOPPER ASSEMBLY



DRIVE TRANSMISSION ASSEMBLY




REAR WHEEL ASSEMBLY




Miller Curber Co. LLC


AUGER ASSEMBLY



BELT GUARD ASSEMBLY



BATTERY ASSEMBLY



ITEM NO.	PART NUMBER	DESCRIPTION
1	45029-01	MC-850 FRAME WELDMENT
2	45015-01	WHEELBARROW HOPPER, LH
3	45140-25	FRAME EXT. MC850/900
4	45015-12	REMOVABLE HOPPER SIDE PLATE
5		HHCS, 1/2-13 UNC x 3" LG.
6	45140-31	FRONT END CLAMP WASHER
7	45003-11	CURBFORM HOLD DOWN SCREW
8	45012-13	HOPPER CLAMP
9		HHCS, 3/8-16 UNC x 2-1/2" LG.
10		LOCK NUT, 3/8-16 UNC
11		USS FLAT WASHER, 1/2"
12		WING NUT, 1/2-13 UNC
13	45050-18	CHAIN GAURD
14		USS FLAT WASHER, 3/8"
15		LOCK WASHER, 3/8"
16		HHCS, 3/8-16 x 1" LG.
17	45013-09	HOPPER ADJUSTING PLATE
18		SAE FLAT WASHER, 5/16"
19		HHCS, 5/16-18 UNC x 3/4" LG.
20		NYLOK LOCK NUT, 5/16-18 UNC
21	45043-04	EMERGENCY STOP SWITCH, ELECTRIC START
22	MS0200	RUBBER HOOD LATCH

ITEM NO.	PART NUMBER	DESCRIPTION
23	45145-01	ENGINE COVER
24	45145-10	ENGINE COVER BRACE
25	45035-01	LIFTING LUG
26		HHCS, 1/2-13 UNC x 1-3/4" LG.
27		SAE FLAT WASHER, 1/2"
28		LOCK NUT, 1/2-13 UNC
29	45157-02	FUEL TANK BRACKET
30		HHCS, 5/16-18 UNC x 1" LG.
31	45145-17	RETRACTABLE PLUNGER
32		LOCK WASHER, 1/4"
33		HHCS, 1/4-20 UNC x 3/4" LG.
34		HHCS, 3/8-16 UNC x 1-1/4" LG.
35	45157-01	PLASTIC FUEL TANK
36	45002-11	MC-860/900 MOTOR MOUNT
37	45016-17	IDLER BRACKET WELDMENT
38	45016-18	IDLER BRACKET RETAINING PLATE
39	45016-21	IDLER BRACKET TUBE
40	45108-07	3/8" CAGE NUT
41	45016-11	IDLER SPROCKET
42	45050-02	2 GROOVE Q.D. SHEAVE
43	45050-03	Q.D. BUSHING FOR 4050-02
44	45050-05	GEAR REDUCER

NOTE:
WHEN ORDERING FASTENERS, PLEASE USE
PAGE REFERENCE (LOWER RIGHT HAND
CORNER) AND ITEM NUMBER.



ITEM NO.	PART NUMBER	DESCRIPTION
45	BE0100	1-1/4" 2-BOLT FLANGE BEARING
46	45050-23	COG "V" BELT
47	45050-16	OUTPUT SHAFT
48	SK0200	15 TOOTH SPROCKET
49	45024-03	SAFETY TORQUE ARM
50		HHCS, 1/2-13 UNC x 1-1/2" LG.
51	45008-10	SHEAVE GAURD
52		SHOULDER BOLT, 5/8-11 UNC x 3/4 DIA x 2" LG.
53	BE0200	1-1/4" 4-BOLT FLANGE BEARING
54		HEX NUT, 1/2-13 UNC
55		LOCK WASHER, 1/2"
56		HHCS, 1/2-13 UNC x 1-1/4" LG.
57		SAE FLAT WASHER, 3/8"
58		HHCS, 3/8-16 UNC x 3/4" LG.
59		HHCS, 5/16-18 UNC x 1-1/2" LG.
60		HHCS, 1/2-13 UNC x 7-1/2" LG.
61		HHCS, 3/8-16 UNC x 4" LG.
62	45024-02	TORQUE ARM COMPRESSION SPRING
63	45024-09	SAFETY TORQUE ARM HANDLE
64	45024-14	SAFETY TORQUE ARM STUD
65	45024-04	SAFETY TORQUE ARM BRACKET
66		HEX NUT, 5/8-11 UNC

ITEM NO.	PART NUMBER	DESCRIPTION
67	45151-01	20.3 HP HONDA ENGINE
68	45151-07	HONDA MUFFLER FOR MC-850/900
69	CL0200	CLUTCH, 1" BORE, HVY. DUTY
70		HHCS, 3/8-16 UNC x 1-3/4" LG.
71	45033-07	TALL WHEEL BRACKET HVY DTY
72	45036-11	JACK HANDLE ASSEMBLY
73	BE0600	JACK ASSEMBLY THRUST BEARING
74	45032-10	JACK SCREW, TALL WHEEL ASSEMBLY
75	MS0400	JACK HANDLE KNOB
76	45158-07	TALL REAR WHEEL FORK ASSEMBLY
77	45032-03	TALL REAR WHEEL HSG ASSY
78	WT0100	8" x 2" RUBBER WHEEL W/ ROLLER BEARING
79	45094-04	AXEL, 3/4-10NC x 10" LG W/ LOCKNUTS
80		USS FLAT WASHER, 3/4"
81	47132-24	CARRIAGE BOLT, 1/2-13 UNC x 3-1/2" LG.
82	47139-37	CARRIAGE BOLT, 1/2-13 UNC x 3" LG.
83		HHCS, 1/4-20 UNC x 1-1/2" LG.
84		LOCK NUT, 1/4-20 UNC
85	45131-03	THROTTLE PLATE CLAMP
86	45131-02	THROTTLE MOUNTING PLATE
87	45132-43	THROTTLE CONTROL
88		HHCS, 1/4-20 UNC x 1-1/4" LG.

NOTE:
WHEN ORDERING FASTENERS, PLEASE USE
PAGE REFERENCE (LOWER RIGHT HAND
CORNER) AND ITEM NUMBER.



ITEM NO.	PART NUMBER	DESCRIPTION
89	45132-44	BULK HEAD FITTING
90	45130-34	20.3 HP HONDA THROTTLE CABLE ASSY.
91	45130-27	HONDA THROTTLE WIRE SWIVEL
92	45026-01	TALL FRONT WHEEL FORK
93	45158-15	TALL FRONT WHEEL FORK
94	45020-14	STEERING HANDLE
95	CG0100	GRIP, HANDLEBAR
96	45140-23	CENTER WHEEL SPACER
97	45140-11	PNEUMATIC WHEEL SPACER
98	45140-12	PNEUMATIC TIRE AND RIM ASSY
99	45140-10	AXEL, 3/4-10NC x 12" LG W/ LOCKNUTS
100	45031-17	CURBER MARKING ROD BACKPLATE
101	45031-11	MC-550/650/850 MARKER POINTER
102	45031-21	FRONT END CLAMP RETAINING NUT
103	45031-18	MARKER HOLDER ROD BRACKET
104		HHCS, 1/2-13 UNC x 6-1/2" LG.
105	45059-08	TIE ROD
106	45059-04	MALE TIE ROD END W/ STUD
107	45059-11	COUPLING NUT, 1/2-20 UNF x 1-1/4" LG.
108		HHCS, 1/2-20 UNF x 1" LG.
109	48200-26	THROTTLE MOUNT KNOB
110	SK0300	23 TOOTH SPROCKET

ITEM NO.	PART NUMBER	DESCRIPTION
111	45050-10	ROLLER CHAIN, 37" LONG
112	45011-01	6" HVY DTY AUGER HOUSING
113	45014-06	6" CAST COMPACTION TUBE
114	45023-01	SOLID AUGER SHAFT
115	45018-09	6" SOLID AUGER, 9" LONG
116	45010-12	6" AUGUR SHAFT GAURD
117		HEX NUT, 3/8-16 UNC
118	45019-29	CENTER BELT GUARD COVER
119	45019-18	RIGHT HAND BELT GUARD WELDMENT
120	45019-19	LEFT HAND BELT GUARD WELDMENT
121	44108-07	MANUAL TUBE MOUNTING CLAMPS
122	44108-01	MANUAL TUBE
123	44108-05	MANUAL TUBE CAP
124	45116-19	WRAP-AROUND BATTERY BOX SIDE
125	45116-20	BATTERY BOX BOTTOM
126	45116-21	BATTERY BOX TOP
127	BT0100	BATTERY, 12V DC
128	BF0100	36" BATTERY POSITIVE CABLE
129	BF0200	BATTERY GROUND CABLE
130	45116-23	BATTERY BOX BOLTS

NOTE:
WHEN ORDERING FASTENERS, PLEASE USE
PAGE REFERENCE (LOWER RIGHT HAND
CORNER) AND ITEM NUMBER.

