




Ref#	Part#	Description	Qty Req'd
1	20012550	LOG SET - COMPLETE	1
1a	20012541	LOG, REAR	1
1b	20012543	LOG, RIGHT FRONT	1
1c	20012542	LOG, LEFT FRONT	1
1d	20012544	LEFT CROSS LOG	1

1e	20012545	RIGHT CROSS LOG	1
2	20012206	EMBER BED ASSEMBLY	1
3	1301194	TOP CLASSIC BLACK	1
3	30003262	TOP EBONY BLACK	1
3	30004933	TOP MAJOLICA BROWN	1
3	2371194	TOP MIDNIGHT BLUE	1
3	30003244	TOP BISCUIT	1
3	30003253	TOP CHESTNUT BROWN	1
3	30003271	TOP VERMONT CLASSIC GREEN	1
3	2321194	TOP BORDEAUX	1
3	30003592	TOP BRICK BLUE	1
3	30003603	TOP COUNTRY COOKWARE GRAY	1
3	30003614	TOP GRANITE GRAY	1
3	30003625	TOP SAGE GREEN	1
4	1601970	SCREEN, TOP	1
5	1301195	GRILL, TOP	1
6	30001376	FRONT CLASSIC BLACK	1
6	30003258	FRONT EBONY BLACK	1
6	30004928	FRONT MAJOLICA BROWN	1
6	30001424	FRONT MIDNIGHT BLUE	1
6	30003240	FRONT BISCUIT	1
6	30003249	FRONT CHESTNUT BROWN	1
6	30003267	FRONT VERMONT CLASSIC GREEN	1
6	30001416	FRONT BORDEAUX	1
6	30003588	FRONT BRICK BLUE	1
6	30003599	FRONT COUNTRY COOKWARE GRAY	1
6	30003610	FRONT GRANITE GRAY	1
6	30003621	FRONT SAGE GREEN	1
7	30001378	DOOR, LEFT CLASSIC BLACK	1
7	30003260	DOOR, LEFT EBONY BLACK	1
7	30004930	DOOR, LEFT MAJOLICA BROWN	1
7	30001426	DOOR, LEFT MIDNIGHT BLUE	1
7	30003242	DOOR, LEFT BISCUIT	1
7	30003251	DOOR, LEFT CHESTNUT BROWN	1
7	30003269	DOOR, LEFT VERMONT CLASSIC GREEN	1
7	30001418	DOOR, LEFT BORDEAUX	1
7	30003590	DOOR, LEFT BRICK BLUE	1
7	30003607	DOOR, LEFT COUNTRY COOKWARE GRAY	1
7	30003612	DOOR, LEFT GRANITE GRAY	1
7	30003623	DOOR, LEFT SAGE GREEN	1
8	30001377	DOOR, RIGHT CLASSIC BLACK	1
8	30003259	DOOR, RIGHT EBONY BLACK	1
8	30004929	DOOR, RIGHT MAJOLICA BROWN	1
8	30001425	DOOR, RIGHT MIDNIGHT BLUE	1
8	30003241	DOOR, RIGHT BISCUIT	1
8	30003250	DOOR, RIGHT CHESTNUT BROWN	1
8	30003268	DOOR, RIGHT VERMONT CLASSIC GREEN	1
8	30001417	DOOR, RIGHT BORDEAUX	1
8	30003589	DOOR, RIGHT BRICK BLUE	1
8	30003600	DOOR, RIGHT COUNTRY COOKWARE GRAY	1
8	30003611	DOOR, RIGHT GRANITE GRAY	1
8	30003622	DOOR, RIGHT SAGE GREEN	1
9	30001413	CONTROL DOOR CLASSIC BLACK	1
9	30003261	CONTROL DOOR EBONY BLACK	1
9	30004931	CONTROL DOOR MAJOLICA BROWN	1

9	30001427	CONTROL DOOR MIDNIGHT BLUE	1
9	30003243	CONTROL DOOR BISCUIT	1
9	30003252	CONTROL DOOR CHESTNUT BROWN	1
9	30003270	CONTROL DOOR VERMONT CLASSIC GREEN	1
9	30001419	CONTROL DOOR BORDEAUX	1
9	30003591	CONTROL DOOR BRICK BLUE	1
9	30003602	CONTROL DOOR COUNTRY COOKWARE GRAY	1
9	30003613	CONTROL DOOR GRANITE GRAY	1
9	30003624	CONTROL DOOR SAGE GREEN	1
10	30001751	LEFT END CLASSIC BLACK	1
10	30003257	LEFT END EBONY BLACK	1
10	30004927	LEFT END MAJOLICA BROWN	1
10	30001777	LEFT END MIDNIGHT BLUE	1
10	30003239	LEFT END BISCUIT	1
10	30003248	LEFT END CHESTNUT BROWN	1
10	30003266	LEFT END VERMONT CLASSIC GREEN	1
10	30001771	LEFT END BORDEAUX	1
10	30003587	LEFT END BRICK BLUE	1
10	30003598	LEFT END COUNTRY COOKWARE GRAY	1
10	30003609	LEFT END GRANITE GRAY	1
10	30003620	LEFT END SAGE GREEN	1
11	30001752	RIGHT END CLASSIC BLACK	1
11	30003256	RIGHT END EBONY BLACK	1
11	30004926	RIGHT END MAJOLICA BROWN	1
11	30001776	RIGHT END MIDNIGHT BLUE	1
11	30003238	RIGHT END BISCUIT	1
11	30003247	RIGHT END CHESTNUT BROWN	1
11	30003265	RIGHT END VERMONT CLASSIC GREEN	1
11	30001770	RIGHT END BORDEAUX	1
11	30003586	RIGHT END BRICK BLUE	1
11	30003597	RIGHT END COUNTRY COOKWARE GRAY	1
11	30003608	RIGHT END GRANITE GRAY	1
11	30003619	RIGHT END SAGE GREEN	1
12	30001753	LEG CLASSIC BLACK	4
12	30003263	LEG EBONY BLACK	4
12	30004934	LEG MAJOLICA BROWN	4
12	30001778	LEG MIDNIGHT BLUE	4
12	30003245	LEG BISCUIT	4
12	30003254	LEG CHESTNUT BROWN	4
12	30003272	LEG VERMONT CLASSIC GREEN	4
12	30001772	LEG BORDEAUX	4
12	30003595	LEG BRICK BLUE	4
12	30003606	LEG COUNTRY COOKWARE GRAY	4
12	30003617	LEG GRANITE GRAY	4
12	30003628	LEG SAGE GREEN	4
13	5003075	GLASS FRAME ASSEMBLY	1
14	1409112	FRAME, GLASS	1
15	1203702	GASKET, GLASS MED. KNIT	7
16	1601290	GLASS, GFP FIREBOX	1
17	1600664	WOOD HANDLE	1
18	1201310	PAN HD, SI 1/4-20 X 3-Z	1
19	30002714	BRUSHED NICKEL INSERT	1
20	30002730	CONTROL DOOR HANDLE ASSEMBLY	1
21	1202437	WASHER, FLAT 1/4-BLK.266 X .629.064	1
22	1201372	CS, HEX HD 1/4-20 X 5/8 - BLK	1

23	30001249	LATCH, FRONT DOOR	1
24	30000879	FK26 FAN SUBASSEMBLY(RADVTC SERIES ONLY)	1
25	20012218	VALVE NOVA SIT820.852(RADVT SERIES ONLY)	1
26a	20003719	VALVE GAS HONEYWELL CONVERTIBLE RFN RV8310E	1
26b	20003720	VAIVE GAS HONEYWELL CONVERTIBLE RFP RV8310E	1
N/S	20009853	VALVE BRACKET - MILLIVOLT	1
27a	10002264	PILOT ASSEMBLY 3WAY N/DV RN 0.199.706	1
27a	10002265	PILOT ASSEMBLY 3WAY N/DV RP 0.199.703	1
27b	20001115	PILOT PSE - NA175	1
27b	20001116	PILOT PSE - LP175	1
27c	20002266	PILOT ASSEMBLY 3WAY DV/RFN CS3003A2009	1
27c	20002268	PILOT ASSEMBLY 3WAY DV/RFP CS3003A2017	1
28	10002266	PILOT TOP CONVERTIBLE	1
29	24D0808	THERMOCOUPLE 24	1
29	24D0808	THERMOCOUPLE 24	1
30	10001297	ELECTRODE IGNITER W/CABLE SIT	1
31	26D0566	THERMOPILE 18 RS	1
31	7533113	THERMOPILE 18 RS	1
32	57886	NUT ELECTRODE SIT 0.974.144	1
33	26D0665	TUBING PILOT W/ FITTING 1/8X24	1
34	20002400	THERMOPILE PSE FOR RF PILOTS - NO LONGER AVAILABLE SUB 26D0566	2
35a	37D0022	PILOT ORIFICE 62 - NG TOP CONVERTIBLE	1
35b	37D0023	PILOT ORIFICE 35 - LP TOP CONVERTIBLE	1
36a	20000908	PILOT ORIFICE PSE RFN	1
36b	20000907	PILOT ORIFICE PSE RFP	1
37a	20012946	ORIFICE HOOD 1.75 MM LP	1
37b	20006927	ORIFICE HOOD 31 (0.120) NATURAL	1
37c	20012554	ORIFICE - HIGH ALTITUDE 33 (0.113) NATURAL	1
38	057958	IGNITER PIEZO W/ NUT SIT	1
39	20010876	BRACKET PIEZO IGNITER (NOT SHOWN)	1
40	20012202	MANIFOLD ASSEMBLY	1
41	20012204	AIR SHUTTER ASSEMBLY	1
42	30000874	TRIM ON/OFF SWITCH	1
43	20002047	TRANSMITTER HONEYWELL RF	1
44	20003561	ANTENNAE, HONEYWELL 395783-1	1
45	10002582	WIRE W/ STRAIGHT TERM 2 END 50	1
47	20004287	GASKET BASE PAN	1
48	1203687	GASKET HE DOOR	1
49	1206122	GASKET CEMENT, 3 OZ.TUBE (NOT SHOWN)	1
50	20012967	RESTRICTOR PLATE	1
51	20012443	RIGHT BURNER SUPPORT	1
52	20012442	TIE BRACKET	1
N/S	30002355	HINGE PIN FOR OPERABLE DOORS	4
N/S	1201842	SPRING, LID - CONTROL DOOR	1
N/S	1601924	CABLE - CONTROL DOOR	1
N/S	20004194	REAR SHROUD	1

iBuyFireplaceParts.com 888-634-4289

iBuyFireplaceParts.com

iBuyFireplaceParts.com 888-634-4289