



# OPERATOR'S SAFETY AND SERVICE MANUAL



## SCS2 & KEY READER

This manual covers the following serial numbers  
and higher for each model listed:

SCS2.....6060007




## SOIL COMPACTION SUPERVISOR 2 & KEY READER

**MBW, Inc.**  
250 Hartford Rd • PO Box 440  
Slinger, WI 53086-0440  
Phone: (262) 644-5234  
Fax: (262) 644-5169  
Email: [mbw@mbw.com](mailto:mbw@mbw.com)  
Website: [www.mbw.com](http://www.mbw.com)

**MBW (UK) Ltd.**  
Units 2 & 3 Cochrane Street  
Bolton BL3 6BN, England  
Phone: 01204 387784  
Fax: 01204 387797

**MBW France S.A.R.L**  
Z.A. d'Outreville  
11 rue Jean Baptiste Néron,  
60540 BORNEL, France  
Phone: 3 44 07 15 96  
Fax: 3 44 07 41 28

L19035/ 04.09.E  
©MBW, Inc. 2009  
Printed in the USA



## Soil Compaction Supervisor 2 Starter Kit

