




Plastic Ice Maker Outlet Boxes With Lead Free Quarter Turn Valve







Ice Maker Box Installation Instructions

- 1) Remove the faceplate that is attached to the ice maker box and save for future installation.
- 2) Using either nails or screws, mount the box to the stud via the flanges on the side of the box.
- 3) Box can be mounted:
 - a) On either side of the stud bay.
 - b) At a height determined by builder/installer.
 - c) In any direction top mount, etc.
- 4) Connect the copper water supply tubing to the ice maker box valve via the sweat/solder connection.
- 5) Check all local codes for appropriate approvals and requirements.
- 6) To the 1/4" outlet of valve attach either:
- a) Copper supply tubing via compression connection.
- b) Poly supply tubing via compression connection brass insert into poly tube is required
- c) Braided hose via threaded connection.
- 7) Connect to the inlet connection of the refrigerator.

Part #	Replacement Component Description
88416	Lead Free Lean Sweat Ice Maker Valve
89440	Plastic Locknut for Solder Valves
89266	Faceplate

Item #	Replacement Component Description	Model #	Case Qty	Packaging
87967	Brass Qtr Turn Valve, Installed, 1/2" Sweat Conx.	AB9700	10	Standard Pack
87981	Brass Qtr Turn Valve, Installed, 1/2" Sweat Conx.	AB9700CP	20	Contractor Pack



500 Distribution Parkway, Collierville, TN 38017 Phone: 800-888-8312 Fax: 901-853-5008 www.ipscorp.com