



Keeping the World Flowing  
for Future Generations

**Thank you for purchasing a Rotork Integrated Ethernet actuator - EtherNet/IP version.**


To ensure correct operation of the actuator, please identify the firmware version of the EtherNet/IP option card fitted in the actuator (instructions below) and use the matching EDS version in the table below.

The files will be available in their respective unzipped directories.

Integrated Ethernet Firmware Version	EDS File Version	Location
v103 or earlier	v1.01	v103 folder
v104	v1.04	v104 folder
v105	v2.01	v105 folder

**Follow the steps below on your IQ3 Pro or IQT3 Pro actuator to identify the actuator's Ethernet Option Card firmware version.**

1. Using a Rotork Bluetooth® Setting Tool Pro, access the 'Main Menu' page by pressing the down arrow button.




## Integrated Ethernet Actuator EtherNet/IP EDS File Versions


2. Navigate to **Assets** and select **Actuator**.



3. Select **Actuator Opt Build**



4. The Ethernet Option Card firmware version should be visible in the list. Please scroll down if the actuator has more options fitted; its type should be EtherNet/IP.



For more information about the EtherNet/IP option card, please refer to the EtherNet/IP technical manual PUB190-001 available on [www.rotork.com](http://www.rotork.com)

Contact us now  
[mail@rotork.com](mailto:mail@rotork.com)  
[www.rotork.com](http://www.rotork.com)



PUB190-401-00  
Issue 12/25